


Panasonic



Hybrid IP-PBX

User Manual

Model No. **KX-TDA15**




Thank you for purchasing a Panasonic Hybrid IP-PBX.
Please read this manual carefully before using this product and save this manual for future use.

KX-TDA15: MPR Version 2.2

Feature Highlights

Call Centre


This PBX can establish Incoming Call Distribution Groups (ICD Group) by which a large volume of calls from the external customers could be received. One extension can act as the supervisor, and monitor other group members.



1.8 Utilising the Call Centre (Page 123)

Voice Mail Integration


You can forward your calls to a voice processing system and let calling parties leave messages in your mailbox when you are unable to receive calls.



1.9.5 If a Voice Processing System is Connected (Page 135)

Wireless System

This PBX optionally supports a Portable Station (PS) system. PSs can be used on the PBX with other wired telephones.



Appendix (Page 195)

PC Phone/PC Console


This PBX supports the PC Phone/PC Console when your computer is connected to certain Panasonic telephones via USB interface. The PC Phone/PC Console provides advanced control and monitoring of your PBX.



Consult your dealer

Easy Operation

If you are using a certain Panasonic telephone that is equipped with a Navigator Key/Jog Dial and a display, it helps you to access the desired feature easily. Also, you will be informed of the arrival of an incoming call or a message waiting by the lamp if it is equipped.



1.1 Before Operating the Telephones (Page 14)

Call Record (Station Message Detail Recording)


This PBX can record or print out call information: date, time, extension no., dialled no., duration, etc.

| Date | Time | Ext | |
|----------|---------|------|-------|
| 01/02/02 | 10:03AM | 1230 | |
| 01/02/02 | 11:07AM | 2230 | |

Consult your dealer

Built-in Simplified Voice Message

You can set incoming calls to be redirected to your message box to let callers leave voice messages when you are unable to answer the phone.



1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (Page 91)

In This Manual,

- Proprietary Telephone is abbreviated as "PT".
Single Line Telephone is abbreviated as "SLT".
Portable Station is abbreviated as "PS".
Proprietary Telephone with a Display is abbreviated as "Display PT".
Digital Proprietary Telephone is abbreviated as "DPT".
- The suffix of each model number is omitted.
- The following icons are used frequently.



Hints



Conditions

Notice

Product specifications are subject to change without notice.

Important Information

WARNING

- **THIS UNIT MAY ONLY BE INSTALLED AND SERVICED BY QUALIFIED SERVICE PERSONNEL.**
- **IF DAMAGE TO THE UNIT EXPOSES ANY INTERNAL PARTS, DISCONNECT THE POWER SUPPLY CORD IMMEDIATELY AND RETURN THE UNIT TO YOUR DEALER.**
- **UNPLUG THIS UNIT FROM THE AC OUTLET IF IT EMITS SMOKE, AN ABNORMAL SMELL OR MAKES UNUSUAL NOISE. THESE CONDITIONS CAN CAUSE FIRE OR ELECTRIC SHOCK. CONFIRM THAT SMOKE HAS STOPPED AND CONTACT AN AUTHORISED PANASONIC FACTORY SERVICE CENTRE.**
- **WHEN RELOCATING THE EQUIPMENT, FIRST DISCONNECT THE TELECOM CONNECTION BEFORE DISCONNECTING THE POWER CONNECTION. WHEN THE UNIT IS INSTALLED IN THE NEW LOCATION, RECONNECT THE POWER FIRST, AND THEN RECONNECT THE TELECOM CONNECTION.**
- **THIS UNIT IS EQUIPPED WITH AN EARTHED PLUG. FOR SAFETY REASONS THIS PLUG MUST ONLY BE CONNECTED TO AN EARTHED OUTLET THAT HAS BEEN INSTALLED ACCORDING TO APPLICABLE REGULATIONS.**
- **TO PREVENT POSSIBLE FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**
- **THE POWER SUPPLY CORD IS USED AS THE MAIN DISCONNECT DEVICE. ENSURE THAT THE AC OUTLET IS LOCATED NEAR THE EQUIPMENT AND IS EASILY ACCESSIBLE.**
- **TO PROTECT THIS UNIT FROM STATIC ELECTRICITY, DO NOT TOUCH ANY EXTERNAL CONNECTORS OF THE UNIT.**

Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Do not use this product near water, for example, near a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
2. Avoid using wired telephones during an electrical storm. There is a remote risk of electric shock from lightning.
3. Do not use a telephone in the vicinity of a gas leak to report the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire, as they may explode. Dispose according to local regulations.

SAVE THESE INSTRUCTIONS



The KX-TDA15E, KX-TDA15NE, KX-TDA15GR, and KX-TDA15CE are designed to interwork with the:

- Analogue Public Switched Telephone Network (PSTN) of European countries
- Pan-European Integrated Services Digital Network (ISDN) using ISDN basic rate access

Panasonic Communications Company (U.K.) Ltd. declares that this equipment is in compliance with the essential requirements and other relevant provisions of Radio & Telecommunications Terminal Equipment (R&TTE) Directive 1999/5/EC.

Declarations of Conformity for the relevant Panasonic products described in this manual are available for download by visiting:

<http://doc.panasonic.de>

Contact:

Panasonic Services Europe GmbH

Panasonic Testing Centre

Winsbergring 15, 22525 Hamburg, F.R. Germany

Attention

- Keep the unit away from heating appliances and devices that generate electrical noise such as fluorescent lamps, motors, and televisions. These noise sources can interfere with the performance of the PBX.
- This unit should be kept free of dust, moisture, high temperature (more than 40 °C), and vibration, and should not be exposed to direct sunlight.
- If you are having problems making calls to outside destinations, follow this procedure to test the outside lines:

1. Disconnect the PBX from all outside lines.
2. Connect known working single line telephones (SLTs) to those outside lines.
3. Make a call to an external destination using those SLTs.

If a call cannot be carried out correctly, there may be a problem with the outside line that the SLT is connected to. Contact your telephone company.

If all SLTs operate properly, there may be a problem with your PBX. Do not reconnect the PBX to the outside lines until it has been serviced by an authorised Panasonic Factory Service Centre.

- Never attempt to insert wires, pins, etc. into the vents or holes of this unit.
- Wipe the unit with a soft cloth. Do not clean the unit with abrasive powders or with chemical agents such as benzene or thinner.
- When using a Panasonic proprietary telephone (PT), use only the correct Panasonic handset.
- For users of PC Phone (Free Licence Version) shipped with KX-T7601 USB Module:
All features of the PC Phone software are available for 90 days from the date of installation.
After this period expires, the following buttons on the Operation Screen will become unavailable:
 - Recording
 - TAM
 - Voice Memo
 - Text Memo
 - Speed

To continue using any of the corresponding features after the trial period, please purchase KX-TDA0350 (PC Phone, 5 licences).

For Future Reference

Please print, record, and retain the following information for future reference.

Note

The serial number of this product can be found on the label affixed to the unit. You should record the model number and the serial number of this unit as a permanent record of your purchase to aid in identification in the event of theft.

| | |
|-------------------|----------------------------------|
| MODEL NO. | _____ |
| SERIAL NO. | _____ |
| DATE OF PURCHASE | _____ |
| NAME OF DEALER | _____ |
| DEALER'S ADDRESS | _____ _____ _____ _____ |
| DEALER'S TEL. NO. | _____ |

Table of Contents

| | | |
|------------|--|------------|
| 1 | Operation | 13 |
| 1.1 | Before Operating the Telephones | 14 |
| 1.1.1 | Before Operating the Telephones..... | 14 |
| 1.2 | Making Calls | 25 |
| 1.2.1 | Basic Calling..... | 25 |
| 1.2.2 | Easy Dialling..... | 30 |
| 1.2.3 | Redial | 34 |
| 1.2.4 | When the Dialed Line is Busy or There is No Answer | 35 |
| 1.2.5 | Accessing the ISDN Service (ISDN Service Access)..... | 44 |
| 1.2.6 | Alternating the Calling Method (Alternate Calling—Ring/Voice)..... | 45 |
| 1.2.7 | Calling without Restrictions | 46 |
| 1.2.8 | To Access Another Party Directly from Outside (Direct Inward System Access [DISA]) | 47 |
| 1.2.9 | Setting Your Telephone from Another Extension or through DISA (Remote Setting) | 50 |
| 1.3 | Receiving Calls | 51 |
| 1.3.1 | Answering Calls..... | 51 |
| 1.3.2 | Answering Hands-free (Hands-free Answerback) | 52 |
| 1.3.3 | Answering a Call Ringing at Another Telephone (Call Pickup) | 53 |
| 1.3.4 | Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])..... | 54 |
| 1.3.5 | Using the ANSWER/RELEASE Button | 55 |
| 1.3.6 | Identifying Malicious Calling Parties (Malicious Call Identification [MCID]) | 57 |
| 1.4 | During a Conversation | 58 |
| 1.4.1 | Transferring a Call (Call Transfer) | 58 |
| 1.4.2 | Holding a Call | 62 |
| 1.4.3 | Talking to Two Parties Alternately (Call Splitting) | 66 |
| 1.4.4 | Answering Call Waiting..... | 68 |
| 1.4.5 | Multiple Party Conversation..... | 72 |
| 1.4.6 | Mute | 81 |
| 1.4.7 | Letting Other People Listen to the Conversation (Off-hook Monitor) | 82 |
| 1.4.8 | Using the Headset (Headset Operation) | 83 |
| 1.5 | Before Leaving Your Desk | 85 |
| 1.5.1 | Forwarding Calls..... | 85 |
| 1.5.2 | Using Voice Messaging (Built-in Simplified Voice Message [SVM]) | 91 |
| 1.5.3 | Showing a Message on the Caller's Telephone Display (Absent Message)..... | 101 |
| 1.5.4 | Preventing Other People from Using Your Telephone (Extension Dial Lock) | 103 |
| 1.6 | Making/Answering an Announcement | 105 |
| 1.6.1 | Paging | 105 |
| 1.6.2 | Answering/Denying a Paging Announcement | 107 |
| 1.7 | Setting the Telephone According to Your Needs | 108 |
| 1.7.1 | Setting the Alarm (Timed Reminder) | 108 |
| 1.7.2 | Refusing Incoming Calls (Do Not Disturb [DND]) | 110 |
| 1.7.3 | Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)..... | 112 |
| 1.7.4 | Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP]) | 113 |
| 1.7.5 | Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR]) | 114 |
| 1.7.6 | Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR]) | 115 |

| | | |
|-------------|--|------------|
| 1.7.7 | Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)..... | 116 |
| 1.7.8 | Turning on the Background Music (BGM) | 117 |
| 1.7.9 | Protecting Your Line against Notification Tones (Data Line Security) | 118 |
| 1.7.10 | Checking the Time Service Status | 119 |
| 1.7.11 | Setting the Paralleled Telephone to Ring (Paralleled Telephone)..... | 120 |
| 1.7.12 | Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode)..... | 121 |
| 1.7.13 | Clearing Features Set at Your Extension (Extension Feature Clear) | 122 |
| 1.8 | Utilising the Call Centre..... | 123 |
| 1.8.1 | Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up) | 123 |
| 1.8.2 | Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor) | 126 |
| 1.8.3 | Forwarding a Waiting Call (Manual Queue Redirection) | 129 |
| 1.9 | Using User-supplied Equipment..... | 130 |
| 1.9.1 | If a Doorphone/Door Opener is Connected | 130 |
| 1.9.2 | If an External Relay is Connected..... | 132 |
| 1.9.3 | If an External Sensor is Connected | 133 |
| 1.9.4 | If a Host PBX is Connected..... | 134 |
| 1.9.5 | If a Voice Processing System is Connected..... | 135 |
| 1.10 | After Moving to a New Location in the Office..... | 141 |
| 1.10.1 | Using the Same Settings as Your Previous Extension (Walking Extension) | 141 |
| 1.11 | Using a Display Proprietary Telephone | 142 |
| 1.11.1 | Using the Call Log..... | 142 |
| 1.11.2 | Using the Directories..... | 146 |
| 1.11.3 | Accessing System Features (System Feature Access) | 152 |
| 2 | Manager Operation..... | 153 |
| 2.1 | Control Features | 154 |
| 2.1.1 | Extension Control..... | 154 |
| 2.1.2 | Time Service Mode Control | 155 |
| 2.1.3 | Restriction Level Control (Dial Tone Transfer)..... | 157 |
| 2.1.4 | Turning on the External Background Music (BGM) | 158 |
| 2.1.5 | Recording Outgoing Messages (OGM)..... | 159 |
| 2.1.6 | Using the Telephones in a Hotel-type Environment (Hospitality Features) | 161 |
| 2.1.7 | Releasing Network Direct Station Selection (NDSS) Monitor | 165 |
| 3 | Customising Your Phone & System..... | 167 |
| 3.1 | Customising Your Phone (Personal Programming)..... | 168 |
| 3.1.1 | Customising Your Phone (Personal Programming) | 168 |
| 3.1.2 | Settings on the Programming Mode..... | 170 |
| 3.1.3 | Customising the Buttons | 180 |
| 3.2 | Manager Programming | 185 |
| 3.2.1 | Programming Information..... | 185 |
| 3.2.2 | Manager Programming | 186 |
| 3.3 | Customising Your System (System Programming) | 188 |
| 3.3.1 | Programming Information..... | 188 |
| 3.3.2 | System Programming..... | 191 |
| 4 | Appendix | 195 |
| 4.1 | Troubleshooting | 196 |
| 4.1.1 | Troubleshooting..... | 196 |
| 4.2 | Feature Number Table | 199 |

| | | |
|--------------------|---------------------------------|------------|
| 4.2.1 | Feature Number Table | 199 |
| 4.3 | What is This Tone? | 210 |
| 4.3.1 | What is This Tone? | 210 |
| 4.4 | Revision History | 214 |
| 4.4.1 | MPR Version 2.2..... | 214 |
| Index | | 215 |



Section 1

Operation


*This chapter shows you step by step how to use each feature.
Read this chapter to become familiar with the many useful
features of this PBX.*

1.1 Before Operating the Telephones

1.1.1 Before Operating the Telephones


◆◆ What Kind of Telephone Can Be Used?

You can use a single line telephone (SLT), such as a rotary pulse telephone or a Panasonic proprietary telephone (PT) such as the KX-T7636. You can also use a Panasonic Portable Station (PS) such as the KX-TCA255 or KX-TD7690. Use the feature depending on the telephone you are using. If you are using a

Panasonic proprietary telephone with a special feature button such as  or a display (Display PT) or both, you can follow the operation with the button or display messages for easy programming.

If you use a large display telephone (e.g., KX-T7636), you can follow the displayed messages to use the features. If your telephone does not have feature buttons and/or a display, you may operate the PBX by entering a feature number instead. Follow the operation for your type of telephone.

If you use a Console, you can use the buttons on the Console as the buttons on the connected proprietary telephone.



- If you use a Panasonic proprietary telephone which does not have feature buttons, you may change one of the unused flexible buttons to a feature button. Refer to "3.1.3 Customising the Buttons".

Registration for Your Portable Station (PS)

You must register your PS in the PBX and determine its extension number before initial use. For PS registration, consult your dealer.


◆◆ Feature Numbers

To use certain features, you need to enter specified feature numbers (and an additional parameter, if required).

There are two types of feature numbers as follows:

- Flexible feature number
- Fixed feature number

Fixed feature numbers cannot be changed. However, you can change the flexible numbers to other numbers for easier use. If you want to change the numbers, consult your dealer. In this manual, the default numbers (factory installed) are used for operations.

A flexible number is shown as  (half-shaded key). Use the new programmed number if you have changed the feature number. Write the new number in "4.2.1 Feature Number Table" (Appendix).

Notice

The default value of a flexible feature number may vary depending on country/area. For more details, consult your dealer.



If you use a single line telephone which does not have the "*" or "#" keys; it is not possible to access features that have "*" or "#" in their feature numbers.

◆◆ **Tone**

You will hear various tones, during or after an operation, for confirmation. Refer to "4.3.1 What is This Tone?" (Appendix).

◆◆ **Display**

In this manual, you will see "the display ...". This refers to the display of a Panasonic proprietary telephone. If your telephone is not a Panasonic display proprietary telephone, the message will not be displayed. If you use a Panasonic display proprietary telephone, the display helps you confirm the settings. Some proprietary telephones also give you easy access to features. A message is displayed depending on the feature. By pressing the corresponding button on the side or at the bottom of the display, or pressing the Navigator Key, you can access the desired feature. Furthermore, depending on the display proprietary telephone, you can operate features or make calls using the display message. Refer to "1.11 Using a Display Proprietary Telephone".

Notice

In this manual, the display messages are described in English.

Your Extension Number

If you use a Panasonic display proprietary telephone, you can check your own extension number on the display. Press the TRANSFER button or Soft (S1) button while on-hook.

◆◆ **Using a Navigator Key/Jog Dial/Volume Key**

The Navigator Key can be used for the display contrast and the volume control or you can search for desired items on the display. Press the Navigator Key/Volume Key or rotate the Jog Dial in the desired direction. The contrast or the volume level and the items will change as follows:

| Navigator Key | Jog Dial | Volume Key |
|---|--|---|
| <p>Up (Level increases)</p> <p>Left Right</p> <p>Down (Level decreases)</p> | <p>Left (anti-clockwise)</p> <p>Right (clockwise)</p> <p>Level decreases Level increases</p> | <p>Up (Level increases)</p> <p>Down (Level decreases)</p> |

Examples

The displays and the illustrations shown as examples are from a telephone connected to the KX-TDA15.

Restrictions

Some features may be restricted at your extension under system programming. Consult your manager or dealer.

Icon Descriptions
















The following icons show you the feature availability, notes and action to use the features.

| | | | |
|--|---|--|--|
| | This feature cannot be used with a single line telephone. | | Seize an outside line (One of the following). <ul style="list-style-type: none"> Press the CO button. Dial automatic line access number 0 or 9. Dial outside line group access number and outside line group number. |
| | See "Programming" for Related Programming if necessary. | | |
| | Off-hook (One of the following). <ul style="list-style-type: none"> Lift the handset. Press the SP-PHONE button. Press the MONITOR button. (To start talking, lift the handset.) Press TALK button. | | Press the Call button on the Doorphone. |
| | On-hook (One of the following). <ul style="list-style-type: none"> Hang up. Press the SP-PHONE button. Press the MONITOR button. Press CANCEL button. | | Press the hookswitch lightly. |
| | Press the corresponding feature button on the proprietary telephone. | | Talk. |
| | Enter the required number. <Example> Enter the account code. | | You will hear a busy, confirmation, dial, ring or ringback tone. <ul style="list-style-type: none"> B. Tone: Busy Tone C. Tone: Confirmation Tone D. Tone: Dial Tone R. Tone: Ring Tone R. B. Tone: Ringback Tone |
| | Dial an extension number. | | Dial outside phone number. |
| | Dial the telephone number. | | |

◆◆ When You Use a Panasonic Proprietary Telephone
















If you use a Panasonic proprietary telephone and the Console, they may have some of the useful feature buttons described below. For a PS user, refer to "Operating Instructions" for PS. These buttons make operations simple. The illustrations may differ from the buttons on your telephone.

Fixed Buttons















| | | | |
|--|---|---|--|
|  | <p>CO: Used to make or receive an outside call. (Button assignment is required.) Also used as feature buttons. (Button assignment is required.) (Only the outside line "number" [e.g., 1, 2] may be shown on some telephones.)</p> |     | <p>SP-PHONE: Used for hands-free operation.</p> |
|     | <p>AUTO DIAL/STORE: Used for System/Personal Speed Dialling or storing programme changes.</p> |   | <p>PAUSE: Used to insert a pause when storing a telephone number. This button also functions as the PROGRAM button when there is no PROGRAM button on your telephone.</p> |
|   | <p>REDIAL: Used to redial the last dialled number.</p> |   | <p>MESSAGE: Used to leave a message waiting indication or call back the party who left the message waiting indication.</p> |

1.1 Before Operating the Telephones

| | | | |
|---|--|---|--|
| <div><div><div>INTERCOM</div><div></div></div><div><div>INT*</div><div></div></div><div><div>INTERCOM</div><div></div></div><div><div>INT*</div><div></div></div></div> | <p>INTERCOM: Used to make or receive intercom calls.</p> | <div><div></div></div> | <p>Soft Buttons: Used to select the item displayed on the bottom of the display.</p> |
| <div><div><div>MONITOR</div><div></div></div><div><div></div><div></div></div></div> | <p>MONITOR: Used for hands-free dialling. You can monitor the party's voice in hands-free mode.</p> | <div><div><div>AUTO ANS</div><div></div><div>MUTE</div></div><div><div></div><div></div></div><div><div>AUTO ANS</div><div></div><div>MUTE</div></div><div><div></div><div></div></div></div> | <p>AUTO ANS (Auto Answer)/MUTE: Used to receive an incoming call in hands-free mode or mute the microphone during a conversation.</p> |
| <div><div><div>TRANSFER</div><div></div></div><div><div></div></div><div><div>TRANSFER</div><div></div></div><div><div></div></div></div> | <p>TRANSFER: Used to transfer a call to another party.</p> | <div><div><div>HOLD</div><div></div></div><div><div></div></div></div> | <p>HOLD: Used to place a call on hold.</p> |

| | | | |
|--|--|---|--|
|   | FLASH/RECALL: Used to disconnect the current call and make another call without hanging up. This button also functions as a CANCEL button while on-hook. |   | CONF (Conference): Used to establish a multiple party conversation. |
|   | VOICE CALL/MUTE: Used to monitor an intercom call automatically, but it cannot be used for hands-free conversations. It also mutes the handset microphone during a conversation. |   | Call Forwarding (FWD)/Do Not Disturb (DND): Used to perform Call Forwarding (FWD) or Do Not Disturb (DND). |
|      | PROGRAM: Used to enter and exit the Programming mode. |   | ANSWER: Used to answer an incoming call. |

1.1 Before Operating the Telephones

| | | | |
|---|---|--|--|
|   | RELEASE: Used to disconnect the line. |       | Navigator Key/Jog Dial/Volume Key: Used to adjust the volume and the display contrast or select desired items. |
|  | Programmable Feature (PF): <i>Located on the upper part of the CO button array or on the DSS Console.</i> Assigns the desired button and used to access the stored feature. Mostly used as a One-touch Dialling button. (Only the "F and number" may be shown on some telephones.) |  | MODE: Used to shift the display to access various features. |
|  | SELECT: Used to select the displayed item or to call the displayed phone number. |  | SHIFT: Used to access the second level of Soft button features. |
|  | ENTER: Used to confirm the selected item. |  | CANCEL: Used to cancel the selected item. |

Customised Buttons

If the term is in parentheses like (Account) in this section, it means a flexible button has been made into an "Account" button. To customise, refer to "3.1.3 Customising the Buttons".

| Buttons | Feature |
|-----------------|--|
| Loop-CO (L-CO) | Used to access an idle outside line for making outside calls. Incoming outside calls from any outside line arrive at this button. |
| Group-CO (G-CO) | Used to access an idle outside line in a specified outside line group for making outside calls. Incoming calls from outside lines in the assigned outside line group arrive at this button. |

| Buttons | Feature |
|---|--|
| Single-CO (S-CO) | Used to access a specified outside line for making or receiving outside calls. |
| Direct Station Selection (DSS) | Used to access an extension with one touch. It is also possible to be changed to the other feature button. |
| One-touch Dialling | Used to access a desired party or system feature with one touch. |
| Incoming Call Distribution Group (ICD Group) | Used to access a specified incoming call distribution group for making or receiving calls. |
| Message | Used to leave a message waiting indication or call back the party who left the message waiting indication. |
| Message for Another Extension | Used to have a Message button for another extension. |
| Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls | Used to forward all calls to a specified destination or refuse. |
| FWD/DND—Outside calls | Used to forward outside calls to a specified destination or refuse. |
| FWD/DND—Intercom calls | Used to forward intercom calls to a specified destination or refuse. |
| Group FWD—Both calls | Used to forward all the calls to your group to a specified destination. |
| Group FWD—Outside calls | Used to forward the outside calls to your group to a specified destination. |
| Group FWD—Intercom calls | Used to forward the intercom calls to your group to a specified destination. |
| Account | Used to enter an account code. |
| Conference | Used to establish a multiple party conversation. |
| Terminate | Used to disconnect the current call and make another call without hanging up. |
| External Feature Access (EFA) | Used to access special features offered by a host PBX or a telephone company. |
| Charge Reference | Used to check the total call charge for your own extension. |
| Call Park | Used to park or retrieve a call in a preset parking zone. |
| Call Park (Automatic Park Zone) | Used to park a call in an idle parking zone automatically. |
| Call Log | Used to show the incoming call information. |
| Call Log for ICD Group | Used to have a Call Log button for incoming call distribution group. |
| Log-in/Log-out | Used to switch between the log-in and log-out mode. |
| Log-in/Log-out of a specified group | Used to have a Log-in/Log-out button for another incoming call distribution group. |
| Log-in/Log-out for all groups | Used to have a Log-in/Log-out button for all groups. |
| Hurry-up | Used to transfer the longest waiting call in the queue of an incoming call distribution group to the overflow destination. |
| Wrap-up | Used to switch the wrap-up status, Ready and Not Ready mode. |
| System Alarm | Used to confirm a PBX error. For more details, consult your dealer. |
| Time Service (Day/Night/Lunch/Break) | Used to switch the time service mode. |

1.1 Before Operating the Telephones

| Buttons | Feature |
|--|---|
| Answer | Used to answer an incoming call. |
| Release | Used to disconnect the line during or after a conversation or to complete a Call Transfer. |
| Toll Restriction/Call Barring | Used to change the toll restriction/call barring level of other extension users temporarily. |
| ISDN Service | Used to access an ISDN service. |
| Calling Line Identification Restriction (CLIR) | Used to switch between the CLIP and CLIR services. |
| Connected Line Identification Restriction (COLR) | Used to switch between the COLP and COLR services. |
| ISDN-Hold | Used to transfer a call using telephone company. |
| Headset | Used to talk using the headset. |
| Time Service Switching Mode (Automatic/Manual) | Used to switch the time service mode, Automatic or Manual. |
| Two-way Record | Used to record a conversation into your own mailbox. |
| Two-way Transfer | Used to record a conversation into the mailbox of a specific extension. |
| One-touch Two-way Transfer | Used to record a conversation into the mailbox of a specific extension with one touch. |
| Live Call Screening (LCS) | Used to monitor your own voice mailbox while an incoming caller is leaving a message and, if desired, intercept the call. |
| Voice Mail Transfer | Used to transfer a call to the mailbox of a specified extension. |
| Network Direct Station Selection (NDSS) | Used to access an extension connected to other PBXs in the network with one touch. |
| CTI | Used to access CTI features. For more details, consult your dealer. |
| Check-in | Used to switch the room status of extensions from Check-out to Check-in. |
| Check-out | Used to switch the room status of extensions from Check-in to Check-out. |


◆◆ How to Follow the Steps

An example of system operation is shown below.

◆◆ **Calling Another Extension**

To call an extension (Intercom Call)

PT/SLT/PS


Off-hook.


▶

extension no.

OR

(DSS)


▶


Talk.

Feature title

Operation steps


The description of the icons are explained on "Icon Descriptions".

 • The DSS button light shows the current status as follows:

Off: The extension is idle.

Red on: Your or another extension is using the line.


Conditions

 • To call using a directory, refer to "1.11.2 Using the Directories".

• **For quick operation**
If you are an operator or dial some extensions frequently, DSS buttons are useful.

• **Hands-free Operation**
You can make an intercom call and have a conversation in hands-free mode using the SP-PHONE button.

Hints


 **Customising Your Phone**

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
Create or edit a Direct Station Selection (DSS) button.

Programming References: The related or required programming is noted.

◆◆ Connection Example

This diagram shows you a connection example.



1.2 Making Calls


1.2.1 Basic Calling

- Calling Another Extension
- Calling an Outside Party
- Making a Call to a Private Network (TIE Line Access)
- Using an Account Code (Account Code Entry)


◆◆ Calling Another Extension

To call an extension (Intercom Call)

When your telephone does not access an outside line automatically



When your telephone accesses an outside line automatically



- The DSS button light shows the current status as follows:
Off: The extension is idle.
Red on: Your or another extension is using the line.



- To call using a directory, refer to "1.11.2 Using the Directories".
- **For quick operation**
If you are an operator or dial some extensions frequently, DSS buttons are useful.
- **Hands-free Operation**
You can make an intercom call and have a conversation in hands-free mode using the SP-PHONE button.




Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
Create or edit a Direct Station Selection (DSS) button.

To call an operator (Operator Call)

You can call an extension or a group assigned as the operator.




- The operator call number (default) varies depending on country/area. For more details, consult your dealer.

◆◆ Calling an Outside Party

You have to seize an outside line before dialling an outside phone number because external calls are made via your PBX.


Select one of the following methods:

To select an idle outside line automatically (Automatic Line Access)




- The automatic line access number (default) varies depending on country/area. For more details, consult your dealer.

To select an idle outside line in the specified outside line group automatically (Outside Line Group Access)



To select the specified outside line



- Each of the S-CO button or G-CO button light shows the current status as follows:
Off: The line is idle.
Red on: The line is in use.
- You may be restricted from making a call to the specified outside party. To make a call, refer to "1.2.7 Calling without Restrictions".



- To confirm number before dialling**, you can enter a phone number and confirm it on the display and then go off-hook. (Predialling)
- Call Charge Reference**
You can confirm your total call charges by pressing the Charge Reference button.
- To make a call to another party without going on-hook**, press the FLASH/RECALL button. It will re-access the outside line and provide external dial tone. Pressing the Terminate button will provide intercom dial tone. You can dial the new phone number without going on/off-hook.
- Hands-free Operation**
You can make an outside call and have a conversation in hands-free mode using the SP-PHONE button.




Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
Create or edit a Loop-CO (L-CO) button, a Group-CO (G-CO) button, a Single-CO (S-CO) button, a Terminate button or a Charge Reference button.


◆◆ **Making a Call to a Private Network (TIE Line Access)**

You can access extensions connected to other PBXs in a private network.

To call



To call with one touch



- **To start monitoring another PBX extension after customising an NDSS button**, go off-hook, press the NDSS button, and go on-hook.
The NDSS button light will show the current status as follows:
Off: The extension is idle.
Red on: The extension is busy.




Customising Your Phone

- **3.1.3 Customising the Buttons**
Create or edit a Network Direct Station Selection (NDSS) button.

◆◆ Using an Account Code (Account Code Entry)

You may give a specified account code to extension users and check their telephone usage. You can specify an account code for each client and check the call duration.



- **A Panasonic proprietary telephone extension user** can enter an account code during a conversation and when hearing reorder tone after the other party hangs up.
- Account codes may use the digits "0" through "9".
- **If you enter the wrong code**, press the "*" key and re-enter the account code.



- You may not be able to make an outside call without an account code. Entry mode is assigned to each user. Ask your manager for your mode.
- **For your convenience**, you can store the code with the phone number in the memory (e.g., Speed Dialling).



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit an Account button.


1.2.2 Easy Dialling

This is convenient for frequently dialled phone numbers.

- With a One-touch Button (One-touch Dialling)
- Using Numbers Stored at Your Extension (Personal Speed Dialling)
- Using Numbers Stored in the PBX (System Speed Dialling)
- To a Preset Number by Going Off-hook (Hot Line)
- Using a Preprogrammed Number (Quick Dialling)

◆◆ With a One-touch Button (One-touch Dialling)

You can store a phone number into the flexible button for one-touch operation.



Customising Your Phone


- 3.1.3 Customising the Buttons
Create or edit a One-touch Dialling button, store the desired phone number or feature number.


◆◆ Using Numbers Stored at Your Extension (Personal Speed Dialling)

You can store numbers at your extension for your personal use.

This feature is also known as Station Speed Dialling.

To store a phone number




To dial

- To call using a directory, refer to "1.11.2 Using the Directories".

◆◆ Using Numbers Stored in the PBX (System Speed Dialling)

You can make calls using speed dialling numbers stored in the PBX.




- To call using a directory, refer to "1.11.2 Using the Directories".


◆◆ To a Preset Number by Going Off-hook (Hot Line)

You can make an outside call simply by going off-hook if you have preprogrammed your phone. This feature is also known as Pickup Dialling.


To store a phone number



To set/cancel



To dial



- **To call another party**, dial the desired party's phone number before the preprogrammed number is dialled.
- You should assign the intercom line as the seized line when going off-hook. (Preferred Line Assignment—Outgoing)
- If cancelling Hot Line is difficult because this feature is activated immediately after going off-hook, consult your dealer.




Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
Select the seized line when going off-hook.



Using a Preprogrammed Number (Quick Dialling)

You can make a call simply by pressing the preprogrammed number for quick dialling. For details, consult your manager or dealer.




- It is a useful feature for Hotel.
For example, to dial the Room Service, dial the digit "3", not the full extension number.

1.2.3 Redial

This is convenient when calling the same outside party again.

- Redialling the Last Number You Dialed (Last Number Redial)

◆◆ Redialling the Last Number You Dialed (Last Number Redial)



- Up to 32 digits can be stored and redialled.
- After pressing REDIAL, if you hear a busy tone again, press REDIAL to retry.



- **Automatic Redial**

To redial automatically, press the SP-PHONE button and then the REDIAL button, or press the REDIAL button directly. It will keep trying the busy number until the called party answers or until a specified timeout.

You can perform other tasks during dialling. To cancel, press the FLASH/RECALL button. Some outside lines may not support this feature.

This feature is not available for the KX-T7665 and PS.

1.2.4 When the Dialed Line is Busy or There is No Answer

- Reserving a Busy Line (Automatic Callback Busy)
- Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])
- Sending a Call Waiting Notification (Call Waiting)
- Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)
- Joining an Existing Call (Executive Busy Override)
- Monitoring Another Extension (Call Monitor)
- To an Extension Refusing the Call (DND Override)

◆◆ Reserving a Busy Line (Automatic Callback Busy)

You can set the telephone to receive callback ringing:

- when a dialed extension becomes idle.
- when your desired outside line that is in use by another extension becomes idle.

You cannot set Automatic Callback Busy for a busy party outside of the PBX.


When you answer the callback ringing:

- For an outside call: The line is seized.
- For an intercom call: The called extension starts ringing automatically.


To set (for both extension and outside line)

PT/SLT/PS


While hearing a busy tone



Enter 6.



C.Tone




On-hook.


To answer the callback ringing from an idle extension

PT/SLT/PS


While hearing a callback ringing



Off-hook.




R.B.Tone




Talk.

To answer the callback ringing from an idle outside line



- If you do not answer the callback ringing within 10 seconds, this feature will be cancelled.


To cancel callback ringing (Automatic Callback Busy Cancel)



◆◆ Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])

You can set the telephone to receive callback ringing when a busy called party on an ISDN line becomes free.


When you answer the callback ringing, the called party's telephone number is automatically dialled.



To answer while hearing a callback ringing




To cancel (CCBS Cancel)



- If you do not answer within a specified time period, this feature will be cancelled.
- Availability of this feature depends on the ISDN service of your telephone company.

◆◆ Sending a Call Waiting Notification (Call Waiting)

You can inform the called party that your call is waiting.
This feature is also known as Busy Station Signalling (BSS).



- **Depending on the other party's telephone**, you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can send a call announcement through the handset (Whisper OHCA), if they are having another conversation using the handset.
Refer to "1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)". For telephones capable of using the OHCA and Whisper OHCA features, consult your dealer.


◆◆ Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)

◆ For a caller

When the called extension is busy or does not answer your call, you can leave a notification so that the called party may call you back.

◆ For a called extension

As a message receiver, the Message button light or Message/Ringer Lamp lets you know that a call has been received. If you receive notification, you can call the caller back by a simple operation.



◆ For a caller

To leave a message waiting indication

PT/SLT/PS

When the called extension is busy or does not answer

Press **MESSAGE**
or enter **4**.

C.Tone

On-hook.

To leave/cancel a message waiting indication

PT/SLT/PS

Off-hook.

Enter ***70**.

1

 Leave
OR

0

 Cancel

Enter **1** to leave
or **0** to cancel.

desired
extension no.


Enter **desired
extension number**.

C.Tone


On-hook.

◆ For a called extension


To check the left message and call back



To call back



To clear message waiting indications left on your extension



- The Message button light or Message/Ringer Lamp shows the current status as follows:
Off: No message
Red on: You have a message.
- The display shows the messages starting with the most recent call.
- At a called extension, the MESSAGE button allows you to clear message waiting indications if you do not want to call the callers back. To clear, press the MESSAGE button and then press the soft button.
- On your PT, you can establish one or more Message for Another Extension buttons. These buttons can accept the message waiting notification of other extensions or various incoming call distribution groups.
 In other words, you can monitor the message waiting notifications of other telephones.
- A single line telephone extension user will receive a special dial tone as message waiting notification when going off-hook.




Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Message button or Message for Another Extension button.


◆◆ Joining an Existing Call (Executive Busy Override)

The preprogrammed extension can call someone who is busy on the telephone and establish a three-party conversation.


To join an intercom call



To join an outside call




To leave a three-party conversation with an outside party and let the two other parties talk (originating extension only)



- To join another conversation, you must have Executive Busy Override enabled at your extension. For more details, consult your dealer.
- For the originating extension to leave a three-party conversation, that party's extension must be enabled through COS programming to transfer calls to outside lines.
- The third party can leave the conversation by simply going on-hook.

◆ **For the originating extension**

To talk to each party alternately




- You can also deny others the possibility of joining your conversation (Default: Allow). Refer to "1.7 Setting the Telephone According to Your Needs".

◆◆ Monitoring Another Extension (Call Monitor)


The preprogrammed extension can monitor another extension.

To monitor



◆◆ To an Extension Refusing the Call (DND Override)

The preprogrammed extension can call someone who has set the DND feature.




1.2.5 Accessing the ISDN Service (ISDN Service Access)

You can access services provided by the ISDN.



To access



- Availability of features depends on the ISDN service of your telephone company.



Customising Your Phone


- 3.1.3 Customising the Buttons
Create or edit an ISDN Service button.

1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)




The caller can alternate the alerting method, either ring or voice, when making an intercom call. On the other hand, any extension can set the alerting method, either ring or voice, when receiving an intercom call.

Ringing (Default): You can call the other party with a ring tone.

Voice-calling: You can talk to the other party immediately after confirmation tone.



To change the method

| PT/SLT/PS | | |
|---|---|--|
| <i>After dialling</i> | | |
|  |  |  |
| Enter *. | | Talk. |



- If the called party uses a single line telephone or portable station, Voice-calling is not available.
- This feature is not available when the called party's telephone is in the Voice Call Deny mode.



Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Alternate Receiving—Ring/Voice**
Select the alerting method, either ring or the other party's voice.


1.2.7 Calling without Restrictions

- Using Your Calling Privileges at Another Extension (Remote COS Access)


◆◆ Using Your Calling Privileges at Another Extension (Remote COS Access)

You can use your calling privileges (Class of Service) at another extension. You may override restrictions which have been set. To use this feature, an original extension number and an extension PIN (Personal Identification Number) are required. You can make a call by entering a verified code and verified code PIN. For the available verified code, ask your manager.

To call (Walking COS)



To call with a verified code (Verified Code Entry)




1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])

- Calling through DISA


◆◆ Calling through DISA

When outside callers access extensions in the PBX, a prerecorded message greets the caller and gives information about how to access an extension. You do not need the operator's assistance.


You may be able to access system features or call an outside party with your password depending on the security mode. Ask your manager for the mode assigned to your PBX.




To call an extension



To call an outside party



To retry






- **WARNING**
There is a risk that fraudulent telephone calls will be made using the Outside-to-Outside Call feature of DISA.
The cost of such calls will be billed to the owner/renter of the PBX.
To protect the PBX from this kind of fraudulent use, we strongly recommend:
 - a) Enabling DISA security (Trunk Security or All Security).
 - b) Keeping your passwords (verified code PIN/extension PIN) secret.
 - c) Selecting complex, random PINs that cannot be easily guessed.
 - d) Changing PINs regularly.
- **Time limit**
Both parties will hear an alarm tone fifteen seconds before the specified time limit. To extend, press any dial button except ✕.
- **If Built-in Automated Attendant service is set**, you can access the desired extension simply by pressing a single digit (0-9) from the options given the prerecorded message.

1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)


You can set the following features on your telephone from another extension or through DISA.

- Call Forwarding (FWD)/Do Not Disturb (DND)
- Changing the Log-in/Log-out Status of Extensions
- Absent Message
- Extension Dial Lock
- Time Service—Changing the Time Mode (Day/Night/Lunch/Break)

From another extension




Through DISA



1.3 Receiving Calls


1.3.1 Answering Calls

PT/SLT/PS



Off-hook.

▶



Talk.

Select one of the following methods:

- Lift the handset to receive the preferred line.
(Default: Ringing line is selected.)
- Press the SP-PHONE button.
- Press the flashing CO, INTERCOM or ICD Group button directly.
- Press the ANSWER button.



- The ICD Group button light shows the current status as follows:
Off: Idle
Green on: The line is in use. (You are using the line.)
Red on: Your extension is in Log-out mode from the incoming call distribution group.



- **Hands-free Operation**
 You can receive a call and have a conversation in hands-free mode using the SP-PHONE button.



Customising Your Phone

- 3.1.2 Settings on the Programming Mode—
Preferred Line Assignment—Incoming
 Select the seized line when going off-hook.
Alternate Receiving—Ring/Voice
 Select the alerting method, either ring or the other party's voice.
- 3.1.3 Customising the Buttons
 Create or edit an Incoming Call Distribution Group (ICD Group) button.

1.3.2 Answering Hands-free (Hands-free Answerback)

You can answer an incoming call without going off-hook as soon as the line is connected. When an intercom call arrives, you will hear the caller talking without the phone ringing. When an outside call arrives, you will hear the caller talking after a preprogrammed number of rings. Hands-free Answerback for outside calls requires system programming. Consult your dealer.



To set/cancel



- The AUTO ANS button light shows the current status as follows:
Off: Not set
On: Set
- For a PS user, refer to "Operating Instructions" for PS.

1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)

- Answering a Call from Another Telephone (Call Pickup)
- Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)


◆◆ Answering a Call from Another Telephone (Call Pickup)

You can answer an incoming call that is ringing at another extension or group from your phone without leaving your desk.

The following types of pickup are available:

Group Call Pickup: Picks up a call within your group.


Directed Call Pickup: Picks up a specified extension's call.



- If you receive a call waiting tone, you can ask a third party to pick up your second call with Directed Call Pickup.
- If there are multiple incoming calls for the same group, the longest waiting call is received first.

◆◆ Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)


You can deny or allow other people to pick up your calls.



1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])

You can be notified of incoming outside calls through an external speaker. These calls can be answered from any extension.

Through an external speaker



- You can also receive a paging announcement via a speaker with this operation.

1.3.5 Using the ANSWER/RELEASE Button

The ANSWER and RELEASE buttons are convenient for operators using headsets.

With the ANSWER button, you can answer all incoming calls.


With the RELEASE button, you can disconnect the line during or after a conversation, or complete transferring a call.



To answer




To transfer a call




To talk to a waiting caller



To transfer an outside call to an extension with a one-touch operation



To end a conversation



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit an Answer button or a Release button.


1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])

You can ask your telephone company to trace a malicious calling party during a conversation or after the calling party hangs up.
You will receive the information on the malicious call later on.


To request MCID

PT/SLT/PS


During a conversation or when hearing a reorder tone after the calling party hangs up.



Press **TRANSFER** or
Recall/hookswitch.



Enter ***7*3**.



Talk or on-hook.



- Availability of this feature depends on the ISDN service of your telephone company.

1.4 During a Conversation

1.4.1 Transferring a Call (Call Transfer)



- Transferring to an Extension on the PBX
- Transferring to an Outside Party Using the PBX Service
- Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)




- You can transfer a held call without talking by going on-hook.
If a call is not retrieved within a specified time, you will hear an alarm as a reminder. And, if an outside call is not answered within a specified time, it is automatically disconnected.
- **If you hear an alarm tone**, the destination extension did not answer the call. Answer the call.

◆◆ Transferring to an Extension on the PBX

To transfer





To transfer with one touch (One-touch Transfer)



- Even if the transferred party does not answer, you can go on-hook.

◆◆ **Transferring to an Outside Party Using the PBX Service**

Some extensions may be restricted from performing this feature.



1.4 During a Conversation






- **Time limit**
Both the caller and the transferred party will hear an alarm tone fifteen seconds before a specified time period.
- **To return to the held call before the destination answers**, press the TRANSFER button, corresponding CO, ICD Group or INTERCOM button, or the hookswitch.



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Direct Station Selection (DSS) button.

◆◆ Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)





- To retrieve the held call, press the TRANSFER button, Recall/hookswitch.
- Even if you go on-hook while transferring a call, it is transferred.
- After the call is transferred, the line becomes idle.



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit an ISDN-Hold button.

1.4.2 Holding a Call

- Holding
- Holding in a System Parking Zone (Call Park)





- **If a call is not retrieved within a specified time**, you will hear an alarm as a reminder. And, if an outside call is not answered within a specified time, it is automatically disconnected.

◆◆ Holding

There are two types of hold. The difference between them is that other people can retrieve your held call (Regular Hold) or not (Exclusive Call Hold). As they can be alternated, ask your manager what the current mode is.


To hold (Call Hold)



To retrieve a call (Call Hold Retrieve)

PT/SLT/PS

● At the holding extension (Call Hold Retrieve)




Off-hook.

Press flashing **CO**
or **INTERCOM**,
or enter *** 50**.

Talk.

● To retrieve an outside call from another extension—only Regular Hold (Call Hold Retrieve—Specified with a held line number)




Off-hook.

Press **CO**, or enter ***53** and then **held line number** (3 digits).

Talk.

● To retrieve an intercom call or outside call from another extension—only Regular Hold (Call Hold Retrieve—Specified with a holding extension number)



Off-hook.

Enter ***51**.

Press **DSS** or dial
holding extension number.

Talk.



- The CO or INTERCOM button light shows the current status as follows:
 - Regular Hold mode
 - Flashing green slowly:** Your held call
 - Flashing red:** Another extension's held call
 - Exclusive Call Hold mode
 - Flashing green rapidly:** Your held call
 - Red on:** Another extension's held call
- **Hold Mode Change (PT only)**
After pressing the HOLD button, if you press the HOLD button again, the status switches from the Regular Hold mode to the Exclusive Call Hold mode or from the Exclusive Call Hold mode to the Regular Hold mode.



- **For simple operation**, you can automatically hold a call by pressing another CO, ICD Group or INTERCOM button, only if preprogrammed (**Automatic Call Hold**). Consult your dealer.

◆ Holding in a System Parking Zone (Call Park)

You can put a call on hold in a common parking zone of the PBX so that any extension can retrieve the parked call. You can use this feature as a transferring feature.


A call can be put into either a specified parking zone (Specified) or any idle parking zone (Auto). If a Call Park button and Call Park (Automatic Park Zone) button have been established, you can select either way to park by simply pressing the corresponding button.

When a call is parked automatically, or more than one call has been parked at the same time, you need to specify the parking zone number to retrieve the required call.

To set

PT/PS


During a conversation


(Call Park)

Press **Call Park**.

PT/PS

During a conversation


TRANSFER

▶

*

5

2

▶

parking zone no.


Specified

▶


*

Auto

▶


C.Tone

▶


On-hook.


Press **TRANSFER**. Enter ***52**.

Enter a specified **parking zone number** (2 digits) or press ***** to park at an idle parking zone automatically.

If you hear a busy tone, enter another parking zone number or press ***** again.

SLT

During a conversation


Recall/hookswitch

▶

*


5

2


▶

parking zone no.

▶


C.Tone

▶


On-hook.

Press **Recall/hookswitch**. Enter ***52**.

Enter a specified **parking zone number** (2 digits).

If you hear a busy tone, enter another parking zone number.


To retrieve (Call Park Retrieve)

PT/PS

(Call Park)

Press a flashing **Call Park**.

PT/SLT/PS


Off-hook.

▶

*

5

2


Enter ***52**.


▶

stored parking
zone no.

Dial **stored parking
zone number** (2 digits).

▶


C.Tone


Talk.



- If a call is parked automatically, confirm the parking zone number on the display.



- **If you hear a reorder tone when retrieving a parked call**, there is no held call. Confirm the stored parking zone number.
- After you park a call, you can perform other operations.




Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Call Park button or Call Park (Automatic Park Zone) button.


1.4.3 Talking to Two Parties Alternately (Call Splitting)

When talking to one party while the other party is on hold, you can swap the calls back and forth (alternately).

To alternate between the parties leaving one party on hold temporarily



To leave the conversation and then let the two parties talk



1.4.4 Answering Call Waiting


- Answering Call Waiting in the PBX
- Answering Call Waiting from the Telephone Company

◆◆ Answering Call Waiting in the PBX



During a conversation, a call waiting tone or voice announcement through the speaker or the handset occurs when an outside call has been received or another extension is letting you know a call is waiting. You must activate this feature to use it. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])

You can answer the second call by disconnecting (1) or holding (2) the current call.

1. To disconnect the current call and then talk to the new party





2. To hold the current call and then talk to the new party




After talking to the new party (second call), you can disconnect (2.1) or hold (2.2) it and then retrieve the first call.


2.1 To disconnect the second call and then talk to the original party



2.2 To hold the second call and then talk to the original party

After holding it, you can talk to the original party. Then, you can disconnect it and then talk to the new party again.






- **Depending on your telephone**, you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can receive an announcement through the handset (Whisper OHCA), if you are having a conversation using the handset.
Refer to "1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)". For telephones capable of using the OHCA and Whisper OHCA features, consult your dealer.
- The caller's name or number is displayed for five seconds in fifteen second intervals while waiting to be answered.




Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Call Waiting Tone Type Selection**
If you select "Tone 1", you will hear the same tone for Call Waiting from an outside party and an extension. If you select "Tone 2", you will hear different tones for Call Waiting from an outside party and an extension.



◆◆ Answering Call Waiting from the Telephone Company

This is an optional telephone company service. You can receive a call waiting tone. For details, consult your telephone company.



- **To return to the original party, repeat the operation.**
- In this case, the FLASH/RECALL button on proprietary telephones must be in External Feature Access (EFA) mode. For information about setting the mode of your FLASH/RECALL button, consult your dealer.

👉 Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit an External Feature Access (EFA) button.



1.4.5 Multiple Party Conversation


- Adding Other Parties during a Conversation (Conference)
- Leaving a Conference (Unattended Conference)
- Leaving a Conference (Leaving Three-party Conference)
- Letting a Third Party Join Your Call (Privacy Release)
- Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)

◆◆ Adding Other Parties during a Conversation (Conference)


You can add one or more parties to your conversation.

To establish a conference call







To establish a conference call when receiving a call from an outside party during a two-party conversation




To add four or more parties to a conference




To add an outside party on hold to a conference



To talk to two parties alternately in a three-party conversation



To disconnect one party and then talk to the other in a three-party conversation



- * In this case, the FLASH/RECALL button on a proprietary telephone must be in Flash/Recall mode. For information about setting the mode of your FLASH/RECALL button, consult your dealer.
- During a three-party conversation, pressing the TRANSFER button or Recall/hookswitch alternates between the other parties in the conversation.
- You can have a conference with a maximum of eight parties (comprising intercom or outside lines) simultaneously.
- During a conversation involving four or more parties, you cannot disconnect one party and maintain the conversation with the other parties.



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Conference button.


◆◆ Leaving a Conference (Unattended Conference)

The person who originated a conference can leave the conference, and allow the other parties to continue the conversation.


To leave a conference



To return while others are talking



To complete a conversation



- **Time limit**

Both parties will hear an alarm tone before a specified timeout. The originating extension user will hear an alarm tone before timeout. The call is disconnected when the timer runs out unless the originating extension returns to the conference.



- **Customising Your Phone**

- 3.1.3 Customising the Buttons
Create or edit a Conference button.

◆◆ Leaving a Conference (Leaving Three-party Conference)

The person who originated a conference with two other parties can leave the conference, and allow the other parties to continue the conversation.

To leave a conference





To complete a conversation




- To leave a conference call involving an outside party or parties and have the conference continue, it is necessary to enable your extension to transfer calls to outside lines through COS programming. Consult your dealer.

◆◆ Letting a Third Party Join Your Call (Privacy Release)


You can let a third party join your current outside call and establish a three-party conversation. You can also leave the conversation and then let the two other parties talk.



To let a third party join your conversation and establish a three-party conversation





To leave the conversation and let the two other parties talk




- Only an S-CO button can be used for this operation.
- To leave a three-party conversation and have the conversation continue, it is necessary to enable your extension to transfer calls to outside lines through COS programming. For more details, consult your dealer.


◆◆ Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)



1.4 During a Conversation



To complete a conversation



Customising Your Phone


- 3.1.3 Customising the Buttons
Create or edit an ISDN-Hold button.

1.4.6 Mute

You can disable the microphone or the handset to consult privately with others in the room while listening to the other party on the phone through the speaker or the handset.



To set/cancel




- The AUTO ANS/MUTE or VOICE CALL/MUTE button light shows the current status as follows:
Off: Normal
Flashing red: Mute
- If mute is used during OHCA, it will become Handset Mute.

1.4.7 Letting Other People Listen to the Conversation (Off-hook Monitor)

You can let other people in the room listen to the conversation through the speaker while continuing the conversation using the handset.



To set/cancel



- The SP-PHONE button light shows the current status as follows:
Off: The voice is heard through the handset.
On: The voice is heard through the speaker and the handset.
- This feature requires system programming. Ask your manager.
- This feature may not be available with certain proprietary telephones. For more details, consult your dealer.




- **Hands-free operation**
You can have a conversation in hands-free mode using the SP-PHONE button. You can perform other tasks simultaneously.
- **Helpful hints for hands-free operation:**
 - **If it is difficult to hear the other party's voice:**
Increase the volume using the Navigator Key, Jog Dial, or Volume Key.
 - **If the other party has difficulty hearing you:**
Decrease the volume.
 - **If the other party reports that your voice echoes:**
Use the telephone in a room that has curtains, carpeting or both.
 - **If parts of the conversation cannot be heard:**
If you and the other party speak at the same time, parts of your conversation may be lost. To avoid this, try to speak alternately.

1.4.8 Using the Headset (Headset Operation)


You can have a conversation using a headset.
 In this case, you must select "Headset on" in programming mode or set the Headset button on (red) in advance.
 This feature is also known as Handset/Headset Selection.




To talk using the headset




To use the handset during a conversation using the headset



To talk in hands-free mode during a conversation using the headset



- 
 The Headset button light shows the current status as follows:
Off: Headset mode off
Red on: Headset mode on
- This feature is not available for the KX-T7665.



Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Headset Operation**
Select the equipment to use.
- 3.1.3 Customising the Buttons
Create or edit a Headset button.

1.5 Before Leaving Your Desk

1.5.1 Forwarding Calls

- Forwarding Your Calls (Call Forwarding [FWD])
- Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)

◆◆ Forwarding Your Calls (Call Forwarding [FWD])

You can have your incoming calls forwarded to a specified destination.

All Calls:

All calls are forwarded. Preset extensions may also forward from their own receiving group.

Busy:

All calls are forwarded when your extension is busy.

No Answer:


All calls are forwarded when you do not answer the call within a specified time period.

Busy/No Answer (BSY/NA):

All calls are forwarded when you do not answer within a specified time period or when your extension is busy.


Follow Me (From):

If you fail to set the above-mentioned "All Calls" to forward before you leave your desk, you can set the same feature from the destination extension.




- You can set the floating extension number of a voice mail group or the SVM card as a forward destination.
- You can set your mobile telephone as the forward destination. The voice mail can be used to receive calls if you are unable to answer.
- Incoming calls can be forwarded up to four times.
- **Boss & Secretary feature**
The extension which has been set as the destination can call the forwarding extension.


<Example>



To set/cancel




To set from another extension




- When using a proprietary telephone, you can set or cancel Call Forwarding by pressing the FWD/DND button (fixed button) instead of "***710**".

To set the timer for "No Answer" and "Busy/No Answer"



To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group)



- The FWD/DND button light shows the current status as follows:
Off: Both features are not set.
Red on: FWD mode
Flashing red slowly: DND mode
- The Group FWD button light shows the current status as follows:
Off: No set
Red on: FWD mode

- The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.

(1) When in the FWD/DND Cycle Switch Mode:

Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:



(2) When in the FWD/DND Setting Mode:

Pressing the FWD/DND button (fixed button) while in idle status will take you directly to the programming mode for the FWD/DND setting.

(Refer to "3.1.2 Settings on the Programming Mode".)

Note

A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.

- Transferred outside calls are also forwarded to the destination assigned for outside calls.
- When intercom calls are set to be handled differently from outside calls (forwarding type, forward destination), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, and/or Group FWD—Outside calls and Group FWD—Intercom calls, because:
 - a) the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) and the Group FWD—Both calls button will indicate the setting for either outside calls or intercom calls, but not both.

Note

The FWD icon on PS display reflects the setting for outside calls only.

- b) pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) or the Group FWD—Both calls button will not change the FWD or DND mode for intercom calls and outside calls separately.



Customising Your Phone


- 3.1.3 Customising the Buttons
Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons, or Group FWD (Both calls, Outside calls, Intercom calls) buttons.

◆◆ Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)


All calls are forwarded to an outside party using ISDN. The following types of call forwarding are provided by the ISDN service.

- Unconditional (**Call Forwarding Unconditional [CFU]**)
- When your extension is busy (**Call Forwarding Busy [CFB]**)
- When you do not answer (**Call Forwarding No Reply [CFNR]**)


To set



To cancel



To confirm the condition



1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM])

Your PBX can provide you with answering machine service if an SVM card is installed. Your extension is assigned a message box, into which callers can leave voice messages for you. After callers reach your message box, they will hear your personal greeting message. You can record two kinds of personal greetings: a normal greeting message and a greeting message for each time mode. You can also play back and clear your greeting messages and the voice messages left by callers.

- Recording a Normal Greeting Message
- Recording a Greeting Message for Each Time Mode
- Redirecting Your Calls to Your Message Box
- Leaving Voice Messages
- Listening to Voice Messages Left by Callers
- Accessing Your Message Box from an Outside Telephone
- Accessing the Message Box of Another Extension from Your Extension




- You may hear a busy tone when trying to access your message box if too many other users are already accessing their message boxes. In that case, wait a few minutes and try again.
- If the used recording space (including greeting messages and voice messages left by callers) for the SVM card reaches a certain limit, the display informs you that the recording space is almost full, and you will hear dial tone 3 when going off-hook.

Dial Tone 3




◆◆ Recording a Normal Greeting Message


To record



To play back




To clear




◆◆ Recording a Greeting Message for Each Time Mode

In addition to a normal greeting message, you can record a specific greeting message for each time mode (day/lunch/break/night).


To record



To play back



To clear




- If both the greeting message for a certain time mode and the normal greeting message have been recorded, callers will hear the greeting message for that time mode. However, if no greeting message has been recorded for a certain time mode, the normal greeting message will be played instead.

◆◆ Redirecting Your Calls to Your Message Box

You can set incoming calls to be redirected to your own message box so that callers can leave voice messages when you cannot answer the phone.

To set/cancel






- The default floating extension numbers are 591 for SVM card 1, and 592 for SVM card 2.

◆◆ Leaving Voice Messages

If the extension user you called is not able to answer your call, and your call is redirected to the message box, you will hear the greeting message. Then, you can leave a voice message for that extension. It is also possible to leave a voice message directly in the message box of a desired extension by following the steps below:

To leave a voice message directly to another extension's message box



- Voice message recording will stop, you will hear a notification tone, and the call will be disconnected, in the following cases:
 - the recording time for the voice message reaches the preprogrammed limit. (default: 120 seconds)
 - the recording space for the SVM card reaches the limit.






- When you are on the phone, you can transfer the call directly to the message box of a desired extension by placing the call on hold temporarily, then pressing *38 + #6 + the desired extension number. This allows the caller to leave a voice message in the message box of the desired extension.

◆◆ Listening to Voice Messages Left by Callers

When a caller leaves a voice message, information about that caller is also recorded as the SVM Log. The SVM Log can be viewed using the display of a PT or PS by pressing the Message button.

To listen to voice messages






- In addition to the caller information that is recorded in the Call Log, the following SVM Log information is recorded with voice messages left by callers:
 - Caller's Name
 - Caller's Telephone Number
 - Time recording started
 - Voice Message Status
 - "New" is displayed for voice messages that have not previously been listened to.
 - "Old" is displayed for voice messages that have previously been listened to.
- You can lock the SVM Log display by using an extension PIN (Personal Identification Number) to prevent other users from viewing the information and from playing back your voice messages (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- If your telephone has a Message for Another Extension button, you can access the message box of another extension and listen to voice messages for that extension.
- If a new voice message has been left in your message box, you will hear dial tone 4 after going off-hook. In addition, if your telephone has a Message button or Message/Ringer Lamp, the corresponding button or lamp will light when a voice message has been left.

Dial Tone 4




- The following operations are available by entering the corresponding number while you hear the recorded voice message.
 - 1: To play back the voice message from the beginning (without a confirmation tone)
 - 2: To go to the next voice message
 - 3: To clear the voice message
(Press the AUTO DIAL/STORE button or enter 1 to confirm.)
 - 4: To call back the caller who left the voice message
 - 5: To go back to the previous voice message
 - #6: To leave a voice message directly in the message box of another extension
(Enter desired extension number.)
 - #8: To play back your greeting message and record a voice message in your own message box
 - #9: To end the call
 - #*: To play back the voice message from the beginning (with a confirmation tone)

To listen to voice messages while your display is locked




- When you press the Message button while on-hook to play back voice messages, Display Lock is temporarily deactivated.

To clear voice messages




◆◆ Accessing Your Message Box from an Outside Telephone

You can remotely access your message box and perform any operations of the SVM feature through an outside line as if you were at your own extension.




- If you hear a reorder tone when you try to leave a voice message directly in the message box of another extension, that message box is unavailable. You can enter another extension number by pressing "*".
- When accessing your message box from an outside telephone, you cannot call back callers who have left voice messages, by pressing 4 while hearing the voice message.

To listen to voice messages left in the message box of another extension



◆◆ Accessing the Message Box of Another Extension from Your Extension

You can access the message box of another extension (for example, to record a greeting message for that extension) by following the steps below:




1.5.3 Showing a Message on the Caller's Telephone Display (Absent Message)


You can show the reason you do not answer, if the caller uses a Panasonic display proprietary telephone. There are eight preprogrammed messages and one for your personal message (16 characters). The selected message is shown on the display of your telephone.

| Message no. | Message (Example) |
|-------------|---|
| 1 | Will Return Soon |
| 2 | Gone Home |
| 3 | At Ext %%% (Extension number) |
| 4 | Back at %:% (Hour:Minute) |
| 5 | Out until %/% (Month/Day) |
| 6 | In a Meeting |
| 7 | |
| 8 | |
| 9 | A message assigned for each extension. (Personal Absent Message) |

To set



To cancel



1.5 Before Leaving Your Desk




- Enter the desired value in the "%" positions. You must enter the correct number of characters as represented by the "%" using 0 to 9 or ✖.
- The default messages can be changed. Consult your dealer.
- To create your personal message (Message no. 9), refer to "3.1.2 Settings on the Programming Mode".


1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock)

You can lock your extension so that other users cannot make inappropriate outside calls. This feature is also known as Electronic Station Lockout.

To lock




To unlock



- **If you forget the extension PIN or cannot unlock your extension**, consult your manager. He can clear your extension PIN. Then, you can set the new PIN and unlock your extension by entering it.
- If your extension is locked by this feature, it cannot perform features as follows:
 - Making outside calls
 - Changing the call forwarding destination
- If you do not set extension PIN, you cannot lock and unlock your extension.

To make an outside call while your extension is locked



1.5 Before Leaving Your Desk



- After you make an outside call, Extension Dial Lock is automatically activated again.

1.6 Making/Answering an Announcement


1.6.1 Paging

- Group Paging
- Paging and then Transferring a Call

◆◆ Group Paging


You can make a voice announcement to proprietary telephones or external speakers or both in the preset group simultaneously.

To page



- If the group which you paged is already being used for paging, you hear a busy tone.

◆◆ Paging and then Transferring a Call




1.6 Making/Answering an Announcement




- After you go on-hook, the caller can talk to the person who answers the page.

1.6.2 Answering/Denying a Paging Announcement

To answer



To allow/deny a paging announcement (Paging Deny)




- The following are extensions that cannot receive a paging announcement:
 - Portable station
 - Single line telephone
 - Proprietary telephone that is ringing or busy
 - Proprietary telephone in Paging Deny mode
 - Proprietary telephone in DND mode
- Even if the announcement is not paging your extension, you can answer it, if it is paging your group.

1.7 Setting the Telephone According to Your Needs


1.7.1 Setting the Alarm (Timed Reminder)

You can receive an alarm at your telephone to remind you of a meeting, appointment or as a wake-up call. The alarm can occur either once or daily (every day until cancelled) at a preset time. When you go off-hook to answer, you will hear a special dial tone or prerecorded message.


To set




To cancel



To stop or answer the ringback




To confirm

- You can also confirm the Timed Reminder by using the soft button.
- The alarm keeps ringing for preprogrammed seconds.
- **If you receive an incoming call during ringback**, the ringing starts after the ringback stops.
- **If you are having a conversation exceeding alarm ringing period**, the ringback will start after your conversation.

1.7.2 Refusing Incoming Calls (Do Not Disturb [DND])

You may set this feature when you are in a meeting or busy.

To set/cancel



- When using a proprietary telephone, you can set or cancel Do Not Disturb by pressing the FWD/DND button (fixed button) instead of "*710".



- The FWD/DND button light shows the current status as follows:
Off: Both features are not set.
Red on: FWD mode
Flashing red slowly: DND mode
- The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.
- (1) When in the FWD/DND Cycle Switch Mode:**
Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:



(2) When in the FWD/DND Setting Mode:

Pressing the FWD/DND button (fixed button) while in idle status will take you directly to the programming mode for the FWD/DND setting.
(Refer to "3.1.2 Settings on the Programming Mode".)

Note

A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.

- If your extension has set this feature, a calling extension will hear DND tone.
- If this feature is set, the Call Forwarding (FWD) feature does not work.
- Specified extensions can override this feature and call DND extensions (DND Override).

- When intercom calls are set to be handled differently from outside calls (DND set/cancel), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, because:
 - a) the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will indicate the setting for either outside calls or intercoms calls, but not both.

Note

The DND icon on PS display reflects the setting for outside calls only.

- b) pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will not change the FWD or DND mode for intercom calls and outside calls separately.



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons.

1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)

During a conversation, you can be informed of a call waiting with a tone or voice announcement through your built-in speaker or handset. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])

Call Waiting Tone:

a waiting tone through the built-in speaker of PT/handset of SLT. To change the tone from PT, refer to "3.1.2 Settings on the Programming Mode".


OHCA:

a voice announcement through the built-in speaker


Whisper OHCA:

a voice announcement through the handset

To set/cancel for intercom calls



To set/cancel for outside calls



- OHCA is only available with certain digital proprietary telephones. For more details, consult your dealer.
- Whisper OHCA is only available with certain digital proprietary telephones. In addition, both you and the other party must use supported telephones. For more details, consult your dealer.

1.7.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])

CLIP:

When making an outside call, you can present your preprogrammed telephone number to the called party.

COLP:


When receiving an outside call, you can present your preprogrammed telephone number to the calling party.

You can select the telephone number sent, either the number of the line used or the number assigned to your extension.

If you select "Public", the calling/called party sees the number of the line used (subscriber's number).

If you select "Your extension", they see the telephone number assigned on your extension.

To show either the number assigned to the outside line or your extension



- Availability of this feature depends on the ISDN service of your telephone company.




- If you use the ICD Group button to make a call to the other party, the telephone number assigned to the ICD Group will be used.

1.7.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])

When receiving an outside call, you can select whether the caller can see your telephone number or not.


To show/prevent



1.7.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])

When making an outside call, you can select whether the called party can see your telephone number or not.

To show/prevent




- You can change the mode by pressing a preset CLIR button while on-hook. The CLIR button light shows the current status as follows:
Off: shows your telephone number.
Red on: prevents your telephone number being displayed.
- Availability of this feature depends on the ISDN service of your telephone company.



Customising Your Phone

- 3.1.3 Customising the Buttons
 Create or edit a Calling Line Identification Restriction (CLIR) button.

1.7.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)



- Some extensions may be prohibited from performing this feature.


1.7.8 Turning on the Background Music (BGM)

You can listen to the background music through your telephone speaker while on-hook. An external music source, such as a radio, must be connected.

If your extension becomes busy (off-hook, making or receiving a call etc.), the music stops temporarily. When you go back on-hook, the music starts again.




To select and set/cancel



1.7.9 Protecting Your Line against Notification Tones (Data Line Security)


You can protect the line against audible notification tones, such as a call waiting tone during a conversation. Set this feature if your extension has a data communication device, such as a computer or fax machine connected to ensure secure data transmission.

To set/cancel



1.7.10 Checking the Time Service Status

You can check the current status of the Time Service on the display.



- The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:
 - Off:** Day mode
 - Green on:** Lunch mode
 - Flashing green:** Break mode
 - Red on:** Night mode
 - Flashing red:** Holiday mode
- Any extension user except the managers can check the current status by pressing the Time Service (Day/Night/Lunch/Break) button.




Customising Your Phone

- 3.1.3 Customising the Buttons
 - Create or edit a Time Service (Day/Night/Lunch/Break) button.

1.7.11 Setting the Paralleled Telephone to Ring (Paralleled Telephone)

In the case where a single line telephone is connected in parallel to your digital proprietary telephone, you can choose whether the paralleled single line telephone will ring to an incoming call or not.
(Default: Ring)



- **Even if "No ring" is selected,** calls can be made and answered on the single line telephone by lifting the handset.
- **If you go off-hook while your paralleled telephone is in use,** the call will switch over to you.
- This feature is not available for the KX-T7665.


1.7.12 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode)

Your PS can be used in parallel with a PT or SLT.


When in this mode, incoming calls to a wired telephone also ring the paired PS.

To set

PS



Press **TALK**.



4

8


Enter ***48**.

1


Enter **1**.

extension no.

Enter **extension number**
of the paired telephone.




C.Tone




Press **CANCEL**.

To cancel

PS



Press **TALK**.




4

8


Enter ***48**.

0

Enter **0**.



C.Tone



Press **CANCEL**.



- Some wired telephones are prohibited from using this feature.
- **If you go off-hook while your paralleled telephone is in use, the call will switch over to you.**

1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear)



You can reset the settings of the following features on your extension to the default settings with one operation.





This feature is also known as Station Programme Clear.



| Features | Default Setting |
|---|----------------------------------|
| Hot Line* | Off |
| Message Waiting—(All the messages that have been left by other extension users) | Off |
| Call Pickup Deny | Allow |
| Call Forwarding (FWD)* | Off |
| Absent Message | Off |
| Paging Deny | Allow |
| Timed Reminder | Cleared |
| Do Not Disturb (DND)* | Off |
| Call Waiting for intercom calls* | Disable (No call) |
| Call Waiting for outside calls* | Disable (No tone) |
| Executive Busy Override Deny | Allow |
| BGM | Off |
| Data Line Security | Off |
| Paralleled Telephone | The telephone in parallel rings. |
| Log-in/Log-out | Log-in |

* These features may not be reset depending on the system programming.

PT/SLT/PS





Off-hook.
Enter *790.
C.Tone
On-hook.


1.8 Utilising the Call Centre

1.8.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)

You can control your status in an incoming call distribution group. When in the Log-out mode, incoming calls to the group will not ring at your extension. When you return, calls will again ring at your extension. (Default: Log-in)
 Even if your extension is logged-in, you can have a specified time period (wrap-up time) when you will not receive calls after completing a previous call. This time can be used for you to write a report and so on.
 You can also manually select "Not Ready" mode to temporarily leave a distribution group.






To set Log-in/Log-out



1.8 Utilising the Call Centre

PT/PS *ICD Group: Incoming Call Distribution Group*


While on-hook

 (Log-in/Log-out) →  Specified
 OR
  All

Press **Log-in/Log-out**. Enter **ICD Group extension number** or *****.

PT/PS








While on-hook



 (Log-in/Log-out of a specified group)

Press **Log-in/Log-out of a specified group**.

To enter/leave the Not Ready mode

PT/SLT/PS

 →     →  Not Ready
 OR
  Ready


 

Off-hook. Enter *** 735**. Enter **1** or **0**. On-hook.

To set/cancel the Not Ready mode or to leave the Wrap-up mode (To enter the Ready mode)

PT/PS

While on-hook

 (Wrap-up)

Press red or flashing red **Wrap-up**.*



- * The status will be as follows:
Ready → Not Ready
Not Ready → Ready
Wrap-up → Not Ready
- The Log-in/Log-out of a specified group button light shows the current status as follows:
Off: Log-in mode
Red on: Log-out mode
- The Wrap-up button alternates the setting of Wrap-up mode, Not Ready mode or Ready mode.
The Wrap-up button light shows the current status as follows:
Off: Ready mode
Red on: Not Ready mode
Flashing red: Wrap-up mode
- In Wrap-up mode/Not Ready mode, your extension does not receive calls through any group, even if it belongs to multiple groups.
- There may be at least one extension in the incoming call distribution group that is in the Log-in mode.
- The Supervisor extension can control the Log-in/Log-out status of other extensions.
For more information, refer to "1.8.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)".




Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Log-in/Log-out button, a Log-in/Log-out of a specified group button or a Wrap-up button.

1.8.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)

- Monitoring the Status of Waiting Calls
- Monitoring and Changing the Log-in/Log-out Status of Extensions

The extension assigned as a Supervisor extension can monitor and control the status of other extensions in an incoming call distribution group. It should have a PT with 6-line display. The display and DSS buttons show as follows:



◆◆ Monitoring the Status of Waiting Calls


The Supervisor extension can monitor the status of calls waiting to be answered in the queue. If an incoming call distribution group has an overflowed call, the display shows the status automatically. The following information is displayed.

<Queuing Monitor>

- The current date/time
- The ICD Group extension number/name
- The number of waiting calls
- The longest waiting time

<Call Log History>


- The date/time when cleared at last time
- The total number of received calls
- The number of overflowed calls
- The number of unanswered calls
- The average waiting time of queuing calls

To monitor**To clear Call Log History**


- The accumulated data is cleared.
"*****" shows if the number to be displayed exceeds the maximum displayable digits.

◆◆ Monitoring and Changing the Log-in/Log-out Status of Extensions

The Supervisor extension can monitor the Log-in/Log-out status of the incoming call distribution group members by the DSS button light. It can also change their Log-in/Log-out status if needed.

To monitor

To change the Log-in /Log-out mode



- The DSS button light shows the current status as follows:
Off: The extension is not in the group.
Green on: Log-in (Ready) mode
Flashing green: Log-in (Not Ready) mode
Red on: Log-out mode


1.8.3 Forwarding a Waiting Call (Manual Queue Redirection)

When your incoming call distribution group is busy and other outside calls arrive, the arriving calls are put in a waiting queue.

Extensions can check the status of the queue with the Hurry-up button light, and forward the longest waiting call in the queue to a preset destination manually.

This feature is also known as Hurry-up Transfer.

To forward the waiting call



- The Hurry-up button light shows the current status as follows:
Off: No waiting call.
Red on: Some calls are waiting.
Flashing red: The number of calls exceeds the manual queue redirection level.



Customising Your Phone

- 3.1.3 Customising the Buttons
 Create or edit a Hurry-up button.

1.9 Using User-supplied Equipment

1.9.1 If a Doorphone/Door Opener is Connected


You can talk to a person at the door through the doorphone. Preprogrammed extensions or an outside party can receive the calls from the doorphone. You can open the door.


- Doorphone Call
- Opening a Door (Door Open)


◆◆ Doorphone Call

To call from the doorphone

Doorphone



Press **doorphone** button.


C.Tone


Talk.


To answer a call from the doorphone



PT/SLT/PS


Off-hook.


To call the doorphone


PT/SLT/PS


Off-hook.

▶   

▶ 
Enter **doorphone number** (2 digits).

▶ 
C.Tone


Talk.



- If no one answers a doorphone call within a specified time period, the call is cancelled.


◆◆ Opening a Door (Door Open)


Some extensions may be prohibited from using this feature.

From a specified extension



From any extension while talking to the doorphone




-  • The door open will be triggered for a specified time period.

1.9.2 If an External Relay is Connected

Preprogrammed extensions can switch on a relay (e.g., alarm) connected to the PBX.

To switch on the relay




- The relay will be switched off after a specified time period.

1.9.3 If an External Sensor is Connected

Preprogrammed extensions can receive an alert call from an external sensor (e.g., security alarm) connected to the PBX.

To answer a sensor call



- If you do not answer a sensor call within a specified time period, the sensor call will stop.


1.9.4 If a Host PBX is Connected

- Accessing External Services (External Feature Access [EFA])

◆◆ Accessing External Services (External Feature Access [EFA])

You can access special features (e.g., Call Waiting) offered by a host PBX or telephone company. This feature is only effective for an outside call.

<Example> To hold the current call and then talk to the new party



- In this case, the FLASH/RECALL button on a proprietary telephone must be in External Feature Access (EFA) mode. For information about setting the mode of your FLASH/RECALL button, consult your dealer.
- Regarding the service code, consult your dealer.

👉 Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit an External Feature Access (EFA) button.

1.9.5 If a Voice Processing System is Connected

You or an outside party can access the Voice Processing System from a telephone.

- Call Forwarding to Voice Mail (Voice Mail Integration)

If your PBX has a Panasonic Voice Processing System connected (e.g., KX-TVP/KX-TVS series) using digital integration, the following features are also available:

- Screening Calls (Live Call Screening [LCS])
- Recording a Conversation

◆◆ Call Forwarding to Voice Mail (Voice Mail Integration)

- To forward your calls to your mailbox
- To transfer a call to a mailbox
- To listen to messages


If you cannot answer calls, you can forward them to your mailbox. You can select the type of incoming calls (Intercom Calls/Outside Calls/Both Calls) that are forwarded.

If your telephone has a Message button, the Message light turns on when a message is left in your mailbox. You will hear an indication tone* when going off-hook, regardless of whether or not your telephone has a Message button.


You can also transfer received outside calls to a mailbox so that calling parties can leave messages. If you create a Voice Mail Transfer button on your phone, the transfer is done without knowing the mailbox number (Voice Mail Transfer).

The duration for recording depends on the voice processing system.



To forward your calls to your mailbox



To transfer a call to a mailbox



To listen to messages



- You can access a voice mail with one touch.



- The default voice mail floating extension number is 500.



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Voice Mail Transfer button or a Message button.

◆◆ Screening Calls (Live Call Screening [LCS])

While a caller is leaving a message in your mailbox, you can monitor the call without answering. If you so desire, you can answer the call while monitoring. There are two methods available (Default: Hands-free mode).

Hands-free mode:

You can monitor the message automatically, live through the telephone speaker.


Private mode:

You will hear an alarm tone while the caller is leaving a message.


Before operating

- Create a Live Call Screening (LCS) button (Personal Programming).
- Select the mode, either Hands-free or Private (Personal Programming).
- Set the extension PIN (Personal Identification Number).
- Set the Live Call Screening feature.

To set Live Call Screening




To cancel Live Call Screening



Operation Flowchart

The operations in the shaded areas can be done hands-free.



- The Live Call Screening (LCS) button light shows the feature status as follows:
Off: LCS is off.
Flashing green rapidly: Alerting in the Private mode.
Flashing green slowly: Monitoring.
Red on: LCS is on.
- The manager extension can clear an extension PIN.
- This feature is available for a single line telephone if it is connected to a proprietary telephone in parallel. (Private mode only)
 To answer the call while monitoring, press Recall/hookswitch.
- Only the handset monitoring in the Private mode is available for PS users.



Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Live Call Screening Mode Set**
 Select the mode, either monitoring the message through the speaker automatically or receiving, while the caller leaves a message.
- 3.1.3 Customising the Buttons
 Create or edit a Live Call Screening (LCS) button.

◆◆ Recording a Conversation


You can record a conversation into a mailbox while talking on the phone.
You can select the mailbox each time you record a conversation.



To record into your mailbox (Two-way Record)

PT/PS

During a conversation

 (Two-way Record)


To stop recording, press this button again.

Press **Two-way Record**.

To record into another mailbox (Two-way Transfer)


PT/PS

During a conversation

 (Two-way Transfer)

Press **Two-way Transfer**.

To stop recording, press this button again.


 (DSS)
OR
another extension no.

Press **DSS** or enter **another extension number**.

To record into another mailbox with one touch (One-touch Two-way Transfer)

PT/PS

During a conversation

 (One-touch Two-way Transfer)

Press **One-touch Two-way Transfer**.



- The Two-way Record button light, Two-way Transfer button light or One-touch Two-way Transfer button light shows the current status as follows:
Off: Not recording.
On: Recording the conversation.



- **Note:**
When you record your Two-way telephone conversations, you should inform the other party that the conversation is being recorded.



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Two-way Record button, a Two-way Transfer button and a One-touch Two-way Transfer button.

1.10 After Moving to a New Location in the Office


1.10.1 Using the Same Settings as Your Previous Extension (Walking Extension)

You can use the same features assigned on your previous extension even if you move to another extension in the office.

You can retain your settings, such as extension number or One-touch Dialling memory, on the new extension.

This feature is also known as Walking Station.

To set



- Your previous extension will receive the old settings of your new extension.
- This feature is available for movement between SLT and SLT, PT and PT or SLT and PT.
- For more information, refer to "3.1.1 Customising Your Phone (Personal Programming)".

1.11 Using a Display Proprietary Telephone

1.11.1 Using the Call Log

This is available for display proprietary telephones and portable stations.

- Calling with the Incoming Call Log
- Calling with the Outgoing Call Log

◆◆ Calling with the Incoming Call Log

When you receive an outside call or an external sensor call, call information is recorded automatically in the incoming call log. A preprogrammed number of calls can be logged per extension.

When the call log is full and other call arrives, the oldest call is deleted.


You can modify the logged telephone number.

When the Call Log button light turns on, there is a call which you did not answer.

The following information is logged.




- Caller's Name
- Date/Time call received
- Answered or Not Answered
Confirmed or Not Confirmed
- Caller's Phone Number

To confirm the log information with the Call Log button



To confirm the log information with the Navigator Key



To clear the log information**To call****To store the caller's information in personal speed dialling**



- The Call Log button light shows the current status as follows:
Off: No incoming call. Or you have already viewed the call log.
Red on: You have missed calls to view.
- If your call is answered by another extension, the caller's information is recorded on the displays of both your extension and the answering extension.
- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- You can also have a Call Log button for an ICD Group (Incoming Call Distribution Group).
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.



Customising Your Phone


3.1.3 Customising the Buttons

Create or edit a Call Log button or Call Log for ICD Group button.


◆◆ Calling with the Outgoing Call Log

You can redial using the outgoing call log.


To call



To call with the REDIAL button



- * System programming is required for this operation. Consult your dealer.
- This operation is available only for digital proprietary telephones with a display.

To store the caller's information in personal speed dialling

- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.

1.11.2 Using the Directories

You can call using the directories (*Personal Speed Dialling Directory, System Speed Dialling Directory and Extension Number Directory*).


Only personal directories can be stored, edited or deleted on your extension.

If a call arrives while you are using a directory, the display will be replaced with the caller's information.

- Calling with the Directory
- Storing Names and Numbers
- Entering Characters

◆◆ Calling with the Directory

To select and call




- * The display order is as follows:
One time: Personal Speed Dialling Directory
Two times: System Speed Dialling Directory
Three times: Extension Number Directory
- To cancel or exit, press the CANCEL or FLASH/RECALL button.
- You can lock your personal speed dialling directory by using an extension PIN (Personal Identification Number), so that you can prohibit access to it (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".




- Directory entries generally should include name and number. If the name is not registered, an entry cannot be displayed.
- The System Speed Dialling Directory can be displayed simply by pressing the AUTO DIAL/STORE button while on-hook.

To make an intercom call using Extension Number Directory when your telephone accesses an outside line automatically



◆◆ Storing Names and Numbers

To store a Personal Speed Dialling Directory item



- Telephone numbers and names displayed are stored using the first spare Personal Speed Dialling memory available.
- For a PS user, refer to "Operating Instructions" for PS.



- For more details, refer to "To store the names and numbers in personal speed dialling" in "3.1.2 Settings on the Programming Mode".

◆◆ Entering Characters

You can enter the following characters. The tables show you the characters available for each button. Table 1 or Table 2 can be programmed.

Table 1 (Standard mode)

| Times Buttons | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------------------|---------|---|---|---|---|---|---|---|---|
| 1 | ! | ? | " | 1 | | | | | |
| 2 | A | B | C | a | b | c | 2 | | |
| 3 | D | E | F | d | e | f | 3 | | |
| 4 | G | H | I | g | h | i | 4 | | |
| 5 | J | K | L | j | k | l | 5 | | |
| 6 | M | N | O | m | n | o | 6 | | |
| 7 | P | Q | R | S | p | q | r | s | 7 |
| 8 | T | U | V | t | u | v | 8 | | |
| 9 | W | X | Y | Z | w | x | y | z | 9 |
| 0 | (Space) | . | , | ' | : | ; | 0 | | |
| * | / | + | — | = | < | > | * | | |
| # | \$ | % | & | @ | (|) | € | £ | # |

Table 2 (Option mode)

| Times Buttons | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|------------------|---------|---|---|---|---|---|---|---|---|----|----|----|----|----|----|
| 1 | ! | ? | " | ä | ö | ü | 1 | | | | | | | | |
| 2 | A | B | C | a | b | c | À | Á | Â | Ã | Ä | Å | Æ | Ç | 2 |
| 3 | D | E | F | d | e | f | Ð | È | É | Ê | Ë | 3 | | | |
| 4 | G | H | I | g | h | i | Ì | Í | Î | Ï | 4 | | | | |
| 5 | J | K | L | j | k | l | 5 | | | | | | | | |
| 6 | M | N | O | m | n | o | Ñ | Ò | Ó | Ô | Õ | Ö | Ø | Œ | 6 |
| 7 | P | Q | R | S | p | q | r | s | Š | ß | 7 | | | | |
| 8 | T | U | V | t | u | v | Ù | Ú | Û | Ü | 8 | | | | |
| 9 | W | X | Y | Z | w | x | y | z | Ý | Ž | 9 | | | | |
| 0 | (Space) | . | , | ' | : | ; | 0 | | | | | | | | |
| * | / | + | — | = | < | > | * | | | | | | | | |
| # | \$ | % | & | @ | (|) | € | £ | # | | | | | | |

Table 2 (Option mode for CE model)

| Times Buttons | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|------------------|---------|---|---|---|---|---|---|---|---|----|----|----|----|----|----|
| 1 | ! | ? | " | ä | ö | ü | 1 | | | | | | | | |
| 2 | A | B | C | a | b | c | Á | Â | Ă | Ä | Å | Ć | Ç | Č | 2 |
| 3 | D | E | F | d | e | f | Ď | Ð | É | Ě | Ë | ě | 3 | | |
| 4 | G | H | I | g | h | i | Í | Î | 4 | | | | | | |
| 5 | J | K | L | j | k | l | Ĺ | Í | 5 | | | | | | |
| 6 | M | N | O | m | n | o | Ň | Ň | Ó | Ô | Õ | Ö | 6 | | |
| 7 | P | Q | R | S | p | q | r | s | Ř | Ř | Š | Ś | Ş | ß | 7 |
| 8 | T | U | V | t | u | v | Ť | Ť | ű | Ú | Ú | Ü | 8 | | |
| 9 | W | X | Y | Z | w | x | y | z | Ž | Ž | Ž | ý | 9 | | |
| 0 | (Space) | . | , | ' | : | ; | 0 | | | | | | | | |
| * | / | + | — | = | < | > | * | | | | | | | | |
| # | \$ | % | & | @ | (|) | € | £ | # | | | | | | |


Table 2 (Option mode for GR model)

| Times Buttons | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------------------|---------|---|---|---|---|---|---|---|---|
| 1 | ! | ? | " | 1 | | | | | |
| 2 | A | B | Γ | 2 | | | | | |
| 3 | Δ | E | Z | 3 | | | | | |
| 4 | H | Θ | I | 4 | | | | | |
| 5 | K | Λ | M | 5 | | | | | |
| 6 | N | Ξ | O | 6 | | | | | |
| 7 | Π | P | Σ | 7 | | | | | |
| 8 | T | Υ | Φ | 8 | | | | | |
| 9 | X | Ψ | Ω | 9 | | | | | |
| 0 | (Space) | . | , | ' | : | ; | 0 | | |
| * | / | + | — | = | < | > | * | | |
| # | \$ | % | & | @ | (|) | € | £ | # |

1.11.3 Accessing System Features (System Feature Access)

You can access a feature with the "Feature Access" menu.

To access "Feature Access" menu and select the feature



| Features | Refer to |
|--------------------------------|---|
| Automatic Callback Busy Cancel | 1.2.4 When the Dialed Line is Busy or There is No Answer |
| Group Call Pickup | 1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup) |
| Directed Call Pickup | 1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup) |
| Doorphone Call | 1.9.1 If a Doorphone/Door Opener is Connected |
| Door Open | 1.9.1 If a Doorphone/Door Opener is Connected |
| External Background Music | 2.1.4 Turning on the External Background Music (BGM) |
| Paging | 1.6.1 Paging |

Section 2

Manager Operation

This chapter shows the manager how to control the other extensions or the PBX.

2.1 Control Features

2.1.1 Extension Control


The manager extension can control the settings of other extensions.

- Changing the Settings of Other Extensions

◆◆ Changing the Settings of Other Extensions

To lock/unlock other extensions (Remote Extension Dial Lock)

This feature is also known as Remote Station Lock Control.



- The manager can use Remote Extension Dial Lock to unlock any extension, whether that extension was locked remotely (Remote Extension Dial Lock) or from the extension itself (Extension Dial Lock).

2.1.2 Time Service Mode Control


The manager extension or the preprogrammed extension can change the time mode (Day, Lunch, Break or Night).

There are two methods (Automatic or Manual) of changing the time modes.


Automatic: enables the time mode for each day of the week to change automatically. You may also change it manually.

Manual: enables to change a mode in manual as follows.

To change the time mode (Day/Night/Lunch/Break)



To select the time service switching mode (Automatic/Manual)



2.1 Control Features



- Besides the time mode, there is Holiday mode. It can change mode once on a specified date.
- The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:
 - Off:** Day mode
 - Green on:** Lunch mode
 - Flashing green:** Break mode
 - Red on:** Night mode
 - Flashing red:** Holiday mode
- The Time Service Switching Mode (Automatic/Manual) button light shows the current status as follows:
 - Off:** Automatic
 - Red on:** Manual




Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Time Service (Day/Night/Lunch/Break) button or a Time Service Switching Mode (Automatic/Manual) button.

2.1.3 Restriction Level Control (Dial Tone Transfer)

The manager extension can change the restriction level, permitting an extension to make a call.



- The restriction level is changed to the preprogrammed level of Toll Restriction/Call Barring button.




Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Toll Restriction/Call Barring button.

2.1.4 Turning on the External Background Music (BGM)

The manager extension can select and broadcast background music in the office through external speakers.

To select and start/stop the background music



2.1.5 Recording Outgoing Messages (OGM)


The manager extension can record three kinds of greeting messages (OGM) as follows:

1. **DISA message:** Used to greet and guide callers so that they access extension group or outside party without operator assistance.
2. **Incoming Call Distribution Group message:** Used to greet and guide callers to an incoming call distribution group.
3. **Timed Reminder message:** Used for a wake-up call message when the extension answers the Timed Reminder.




All messages have their own extension numbers. You can select the desired message. You have two methods for recording a message. One is recorded using the handset, and the other is recorded from an external BGM (MOH) port.


To record




To play back



To record from an external BGM (MOH) port



To clear the message



- Record voice messages only; avoid the recording of music.



- The default of OGM floating extension numbers is 5xx (xx: two-digit number of message).

2.1.6 Using the Telephones in a Hotel-type Environment (Hospitality Features)

The hotel operator can check in or check out guests from his extension. When the hotel operator presses a flexible button assigned as "Check-in" or "Check-out" on his extension, the extension will switch to Room Status Control mode, and DSS button lights will show the current room status of extensions. Other features can also be used in a hotel-type environment.

- Check-in
- Check-out
- Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)
- Recording room information using a room extension




- The hotel operator must be using a 6-line display PT.
- Each DSS button light shows the current status as follows:
Off: Check-out
Red on: Check-in
- While in Room Status Control mode, the hotel operator extension is considered to be busy.
- While in Room Status Control mode, the display, INTERCOM button, and flexible buttons do not operate for other telephone features.
- Some of the operations in this section require system programming. Consult your dealer.

◆◆ Check-in

The hotel operator can change the room status of extensions to check-in by using the Check-in button assigned on his extension.

To check in




- After check-in, Remote Extension Dial Lock is deactivated, and the guest can make outside calls from the room extension. (Refer to "2.1.1 Extension Control".)
- After check-in, all billing data previously charged to the extension will be cleared automatically.
- When the room status of extensions is changed, detailed room status information is recorded automatically. This requires system programming.
 <Example>

| Date | Time | Ext | CO | Dial Number |
|----------|---------|------|----|-------------|
| 02/02/00 | 03:07PM | 1234 | | Check in |

◆◆ Check-out

The hotel operator can change the room status of extensions to check-out by using the Check-out button assigned on his extension.


To check out




◆◆ Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)

The hotel operator can remotely set/cancel a Timed Reminder to a room extension. He can also confirm the current setting.


To set



To cancel



To confirm






- Timed Reminder can also be set from the room extension. (For information about setting Timed Reminder, refer to "1.7.1 Setting the Alarm (Timed Reminder)".) The most recent setting will be valid no matter which extension made the setting.
- When a Timed Reminder starts, and when it is answered or not answered, detailed Timed Reminder information is recorded automatically. This requires system programming.
<Example>

| Date | Time | Ext | CO | Dial Number |
|----------|---------|------|----|--------------------------|
| 02/02/00 | 02:45PM | 1234 | | Timed Reminder/Start |
| 02/02/00 | 02:46PM | 1234 | | Timed Reminder/No Answer |
| 02/02/00 | 02:47PM | 1234 | | Timed Reminder/Answer |

Recording room information using a room extension

Room information can be recorded from a room extension using up to 8 preprogrammed messages (1-8). Depending on the content of the messages, a variety of information can be recorded. For a list of preprogrammed messages, consult your dealer.

To record



- * If you see "%" signs, you are required to enter a parameter. Enter values in the "%" positions using 0 to 9 or ✖.
- <Example>
If "Snack %%.%" has been programmed as message number 1 (for recording charges for room snacks consumed), hotel employees would enter data as in the example below using the room extension:


* 761 1 0300 #
 └─┬──────────┘
 message no. parameter
 (Snack charge)

Data similar to the example below is recorded.

| Date | Time | Ext | CO | Dial Number |
|----------|---------|------|----|-------------|
| 02/02/00 | 10:45AM | 1234 | | Snack 03.00 |

2.1.7 Releasing Network Direct Station Selection (NDSS) Monitor

NDSS buttons can be customised on any extension connected to your PBX. An NDSS button allows an extension user to monitor another extension connected to another PBX in a private network. The NDSS button light shows the current status of the monitored extension in the same way as a DSS button. When it becomes unnecessary to monitor an extension connected to another PBX, the manager can stop the PBX from monitoring it. Any NDSS buttons set to monitor that extension will also stop monitoring.



- To restart monitoring of an extension after performing this operation, go off-hook, press the corresponding NDSS button, and go on-hook.



Customising Your Phone

- 3.1.3 Customising the Buttons
Create or edit a Network Direct Station Selection (NDSS) button.

Section 3

Customising Your Phone & System

This chapter shows you how to customise your individual telephone or PBX according to your needs. Find the desired setting and program as necessary.

3.1 Customising Your Phone (Personal Programming)

3.1.1 Customising Your Phone (Personal Programming)

You can customise your telephone features. For example, you can change the initial settings or button features according to your needs.

- Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])




- If you change your desk and extension, refer to "1.10.1 Using the Same Settings as Your Previous Extension (Walking Extension)".


◆◆ Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])

You can assign a password to each extension.
The following features require an extension PIN.

1. Screening calls (Live Call Screening [LCS])
2. Prohibiting other people from seeing your personal speed dialling directory, call log, SVM log, and from playing back the voice messages in your message box (Display Lock)
3. Using the same settings as your extension at other extensions (Walking Extension)
4. Remote Control Operation (Walking COS)
5. Extension Dial Lock Clear

To set



To cancel

- **WARNING**

There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).

The cost of such calls will be billed to the owner/renter of the PBX.

To protect the PBX from this kind of fraudulent use, we strongly recommend:

- a) Keeping your PIN secret.
- b) Selecting a complex, random PIN that cannot be easily guessed.
- c) Changing your PIN regularly.

- Valid numbers for an extension PIN are "0" through "9".
- If the wrong extension PIN is entered a preprogrammed number of times, the PIN is locked.
- If you forget your extension PIN or your extension PIN is locked, your manager can clear the extension PIN and extension PIN lock.

3.1.2 Settings on the Programming Mode

You can programme features using the programming mode.

- Setting Features
- Clearing Features




- To exit at any time, lift the handset.
- To enter the programming mode when using a PS, refer to "Operating Instructions" for PS.

◆◆ Setting Features

The default settings are shown in bold letters. For later reference, place a check mark in the boxes below to indicate your customised setting.

Notice




The default value may vary depending on country/area. For more details, consult your dealer.



| Item | Programming Input | Selection & Parameter | |
|---|---|--|---|
| Your extension information | <input type="text" value="0"/> <input type="text" value="0"/> | PT: The display shows the PBX number, slot number and port number. <example> EXT1050:10308 PBX no. <input type="text" value="1"/> <input type="text" value="0"/> <input type="text" value="5"/> Port no. Slot no. <input type="text" value="1"/> <input type="text" value="0"/> <input type="text" value="3"/> | |
| Preferred display contrast level from the 4 levels available (Display Contrast Selection)*1 | <input type="text" value="0"/> <input type="text" value="1"/> | <input type="text" value="1"/> | <input type="checkbox"/> Light |
| | | <input type="text" value="2"/> | <input type="checkbox"/> Little Light |
| | | <input type="text" value="3"/> | <input type="checkbox"/> Little Dark |
| | | <input type="text" value="4"/> | <input type="checkbox"/> Dark |


| Item | Programming Input | Selection & Parameter | |
|---|-------------------|------------------------------|--|
| Which display language do you prefer? (Display Language Selection) | 0 2 | 1 | <input type="checkbox"/> English |
| | | 2 | <input type="checkbox"/> 2nd Language |
| | | 3 | <input type="checkbox"/> 3rd Language |
| | | 4 | <input type="checkbox"/> 4th Language |
| | | 5 | <input type="checkbox"/> 5th Language |
| Would you like the call duration to be shown automatically on the display when answering an outside call? (Display Switching Mode) | 0 3 | 0 | <input type="checkbox"/> No—Manual (The display keeps showing all of the outside caller's information unless you change it to the call duration manually.) |
| | | 1 | <input type="checkbox"/> Yes—Automatic (The first line of the display will change to the call duration automatically when you answer an outside call.) |
| Would you like to turn on the display backlight of the KX-T7633/KX-T7636? (Display Backlight Selection)*1 | 0 4 | 0 | <input type="checkbox"/> Yes—ON in use |
| | | 1 | <input type="checkbox"/> Yes—always ON |
| | | 2 | <input type="checkbox"/> No—always OFF |
| Would you like to dial a preset number simply by going off-hook? | 1 1 | desired no. (max. 32 digits) | |
| | 1 2 | 0 | <input type="checkbox"/> Do not use |
| | | 1 | <input type="checkbox"/> Use |
| Should you prevent your number being displayed on the called party's telephone? (Calling Line Identification Restriction [CLIR]) | 1 3 | 0 | <input type="checkbox"/> No—Allows your number to be displayed |
| | | 1 | <input type="checkbox"/> Yes—Prevent your number being displayed |
| Which number should be displayed on the called and calling party's telephone? (Calling/Connected Line Identification Presentation [CLIP/COLP]) | 1 4 | 0 | Caller ID assigned to your extension |
| | | 1 | Caller ID assigned on the outside line being used |

3.1 Customising Your Phone (Personal Programming)

| Item | Programming Input | Selection & Parameter | |
|--|-------------------|---|--|
| Which do you prefer to seize when you go off-hook to make calls? (Preferred Line Assignment—Outgoing) | 1 9 | 0 | <input type="checkbox"/> No line |
| | | 1 | <input type="checkbox"/> An idle outside line |
| | | 2 + CO button no. (01-36)* ² or  (CO) | <input type="checkbox"/> A CO/ICD Group button |
| | | 3 or INTERCOM  | <input type="checkbox"/> Intercom |
| Which line do you prefer to answer when you go off-hook? (Preferred Line Assignment—Incoming) | 2 0 | 0 | <input type="checkbox"/> No line |
| | | 1 | <input type="checkbox"/> The longest ringing line (when multiple calls arrive) |
| | | 2 + CO button no. (01-36)* ² or  (CO) | <input type="checkbox"/> An assigned outside button |
| How do you prefer to receive an intercom call? (Alternate Receiving—Ring/Voice)* ¹ | 2 1 | 0 | <input type="checkbox"/> Ringing (Tone Call) |
| | | 1 | <input type="checkbox"/> Directly—The party's voice is heard without ringing. |
| | | 2 | <input type="checkbox"/> Ring only—Prohibiting the caller switching to the voice mode. |
| Should the single line telephone in parallel ring? (Paralleled Telephone)* ^{1*3} | 2 2 | 0 | <input type="checkbox"/> No—The telephone will not ring. |
| | | 1 | <input type="checkbox"/> Yes—The telephone will ring. |

| Item | Programming Input | Selection & Parameter | |
|--|-------------------|------------------------------|---|
| Do you prefer to answer a call without going off-hook regardless of the AUTO ANS button status? (Forced Answerback Selection)* ¹ | 2 3 | 0 | <input type="checkbox"/> No—Disable |
| | | 1 | <input type="checkbox"/> Yes—Enable |
| Which service do you prefer when a calling party is recording a message in your mailbox? (Live Call Screening Mode Set)* ¹ | 2 5 | 0 | <input type="checkbox"/> You can monitor the message through the telephone speaker. (Hands-free mode) |
| | | 1 | <input type="checkbox"/> Only an alarm tone is heard. (Private mode) |
| Would you like to keep recording after answering the call in the LCS mode? (LCS Mode Set [After Answering]) | 2 6 | 0 | <input type="checkbox"/> No—Stop recording |
| | | 1 | <input type="checkbox"/> Yes—Keep recording |
| Do you prefer to receive call waiting for outside calls? | 3 0 | 0 | <input type="checkbox"/> No (No tone) |
| | | 1 | <input type="checkbox"/> Yes (Tone) |
| Which type of call waiting for intercom calls do you prefer? (Call Waiting Selection) | 3 1 | 0 | <input type="checkbox"/> No call |
| | | 1 | <input type="checkbox"/> Tone |
| | | 2 | <input type="checkbox"/> Voice announcement through the built-in speaker (OHCA)* ⁴ |
| | | 3 | <input type="checkbox"/> Voice announcement through the handset (Whisper OHCA)* ⁴ |
| Which type of call waiting tone do you prefer? (Call Waiting Tone Type Selection) | 3 2 | 0 | <input type="checkbox"/> Tone 1 |
| | | 1 | <input type="checkbox"/> Tone 2 |
| Would you like to show a message on the caller's telephone display? (Absent Message) | 4 0 | 0 | <input type="checkbox"/> No—Off |
| | | message no. (1-8) | <input type="checkbox"/> Yes—Shows the selected message. |
| | | 9 | <input type="checkbox"/> Yes—Shows your personal message. |
| Creating your personal message (Personal Absent Message) | 4 1 | message (max. 16 characters) | |

3.1 Customising Your Phone (Personal Programming)

| Item | Programming Input | Selection & Parameter | |
|--|--|--|--|
| Where are your incoming calls forwarded or refused? (Call Forwarding [FWD])/Do Not Disturb [DND] | <div> <div>5</div><div>0</div> </div> <div>  (for both calls) </div> <div> <div>5</div><div>1</div> </div> <div> (for outside calls) </div> <div> <div>5</div><div>2</div> </div> <div> (for intercom calls) </div> | <div>0</div> | <input type="checkbox"/> Off |
| | | <div>1</div> | <input type="checkbox"/> Do Not Disturb (DND) |
| | | <div>2</div> + desired no. (max. 32 digits) | <input type="checkbox"/> All—Forward all calls |
| | | <div>3</div> + desired no. (max. 32 digits) | <input type="checkbox"/> Busy—Forwarded when your extension is busy. |
| | | <div>4</div> + desired no. (max. 32 digits) | <input type="checkbox"/> No Answer—Forwarded when you do not answer. |
| | | <div>5</div> + desired no. (max. 32 digits) | <input type="checkbox"/> Busy/No Answer—Forwarded when you do not answer or when your extension is busy. |
| To set the timer for "No Answer" and "Busy/No Answer" (FWD N/A Timer) | <div>5</div> <div>3</div> | <div></div> (0-120) seconds (Default: 15 seconds) | |
| Should you prohibit other people from picking up your calls? (Call Pickup Deny) | <div>6</div> <div>0</div> | <div>0</div> | <input type="checkbox"/> No—Allow |
| | | <div>1</div> | <input type="checkbox"/> Yes—Deny |
| Do you use the headset? (Headset Operation)*1*3 | <div>6</div> <div>1</div> | <div>0</div> | <input type="checkbox"/> No—Headset off |
| | | <div>1</div> | <input type="checkbox"/> Yes—Headset on |
| Do you prohibit other people from joining your conversation? (Executive Busy Override Deny) | <div>6</div> <div>2</div> | <div>0</div> | <input type="checkbox"/> No—Allow |
| | | <div>1</div> | <input type="checkbox"/> Yes—Deny |
| Would you like to prohibit paging announcements? (Paging Deny)*1 | <div>6</div> <div>3</div> | <div>0</div> | <input type="checkbox"/> No—Allow |
| | | <div>1</div> | <input type="checkbox"/> Yes—Deny |
| Do you prefer to hear the key pad tone? (Key Pad Tone Set)*1 | <div>6</div> <div>4</div> | <div>0</div> | <input type="checkbox"/> No—Off |
| | | <div>1</div> | <input type="checkbox"/> Yes—On |
| Do you want background music through your telephone speaker while on-hook? (Background Music [BGM])*1 | <div>6</div> <div>5</div> | <div>0</div> | <input type="checkbox"/> No—Off |
| | | <div>1</div> <div>1</div> | <input type="checkbox"/> Yes—On |

| Item | Programming Input | Selection & Parameter | |
|---|-------------------|--|---|
| Would you like to set your extension PIN or change a stored extension PIN to new one? (Extension PIN [Personal Identification Number]) | 9 0 | extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN | To set an extension PIN |
| | | stored extension PIN + new extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN | To change a stored extension PIN to new one |
| To prevent other people from using your telephone (Extension Dial Lock) | 9 1 | extension PIN (max. 10 digits) + 0 | <input type="checkbox"/> To unlock |
| | | extension PIN (max. 10 digits) + 1 | <input type="checkbox"/> To lock |
| To prevent other people from seeing your personal speed dialling directory, call log, SVM log, and from playing back the voice messages in your message box (Display Lock)*1 | 9 2 | extension PIN (max. 10 digits) + 0 | <input type="checkbox"/> To unlock |
| | | extension PIN (max. 10 digits) + 1 | <input type="checkbox"/> To lock |
| Do you prefer to set the One-touch dialling only? (One-touch Dialling Assignment Mode Selection) | # * | 0 | <input type="checkbox"/> No—Normal (Any Flexible CO buttons can be modified.) |
| | | 1 | <input type="checkbox"/> Yes—Only One-touch dialling buttons can be modified. However, to modify them, there is no need to enter "2" before the number. |

*1: Not available for a PS

*2: CO button numbers (25-36) are available only when the Add-on Key Module is set up to your telephone.

*3: Not available for the KX-T7665

*4: Only available for certain digital proprietary telephones. Consult your dealer.




- **WARNING**
There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).
The cost of such calls will be billed to the owner/renter of the PBX.
To protect the PBX from this kind of fraudulent use, we strongly recommend:
 - a) Keeping your PIN secret.
 - b) Selecting a complex, random PIN that cannot be easily guessed.
 - c) Changing your PIN regularly.
- After the programme number is entered, the programme title is displayed.
The programming screen can be changed with the Navigator Key (Up or Down).




- You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.

To store the names and numbers in personal speed dialling



- * To enter characters, refer to "Entering Characters".

To edit the names and numbers of personal speed dialling




◆◆ Clearing Features

You can clear or change to features as follows:

| Features | Default Setting |
|---|---|
| Display Switching Mode | Automatic |
| Hot Line | Off |
| Calling Line Identification Restriction [CLIR] | Allow |
| Calling/Connected Line Identification Presentation [CLIP/COLP] | Caller ID assigned on your extension |
| Preferred Line Assignment—Outgoing | Intercom |
| Preferred Line Assignment—Incoming | The longest ringing line |
| Alternate Receiving—Ring/Voice | Ringing (Tone Call) |
| Paralleled Telephone | Paired SLT will ring |
| Forced Answerback Selection | Disable |
| Live Call Screening Mode Set | Hands-free mode |
| LCS Mode Set [After Answering] | Stop recording |
| Call Waiting Selection—Intercom/Outside Calls | Disable (No call/No tone) |
| Call Waiting Tone Type Selection | Tone 1 |
| Absent Message | Off |
| Personal Absent Message | Cleared |
| Call Forwarding [FWD]/Do Not Disturb [DND]—Intercom/Outside Calls | Off |
| FWD N/A Timer | 15 seconds |
| Call Pickup Deny | Allow |
| Headset Operation | Headset off |
| Executive Busy Override Deny | Allow |
| Paging Deny | Allow |
| Key Pad Tone Set | On |
| Background Music [BGM] | Off |
| Data Line Security | Off |
| Connected Line Identification Restriction [COLR] | Allow |
| Log-in/Log-out | Log-in |
| Message Waiting | Off |
| Timed Reminder | Cleared |

To set




- If you do not desire that the Call Waiting, FWD/DND or Hot Line to be cleared by this feature, please ask your dealer.

3.1.3 Customising the Buttons

You can change the flexible CO buttons/DSS buttons, and programmable feature (PF) buttons on PTs, DSS Consoles, Add-on Key Modules, and PSs to the following feature buttons. For example, if your telephone has more CO buttons than available outside lines, you may change unused CO buttons to one-touch buttons.



- To enter the programming mode when using a PS, refer to "Operating Instructions" for PS.



| Buttons | Programmable Button | | | Programming Input |
|---|---------------------|-----|----|---|
| | CO | DSS | PF | |
| Loop-CO (L-CO) | ✓ | ✓ | | * |
| Group-CO (G-CO) | ✓ | ✓ | | # + Outside line group no. (2 digits) |
| Single-CO (S-CO) | ✓ | ✓ | | 0 + Outside line no. (3 digits) |
| Direct Station Selection (DSS) | ✓ | ✓ | | 1 + Extension no. |
| One-touch Dialling*1 | ✓ | ✓ | ✓ | 2 *2 + Desired no. (max. 32 digits) |
| Incoming Call Distribution Group (ICD Group) | ✓ | ✓ | | 3 0 + Incoming call distribution group extension no. |
| Message | ✓ | ✓ | | 4 0 |
| Message for Another Extension | ✓ | ✓ | | 4 0 + Extension no./Incoming call distribution group extension no. |
| Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls | ✓ | ✓ | | 4 1 |
| FWD/DND—Outside calls | ✓ | ✓ | | 4 2 |
| FWD/DND—Intercom calls | ✓ | ✓ | | 4 3 |


| Buttons | Programmable Button | | | Programming Input |
|--------------------------------------|---------------------|-----|----|---|
| | CO | DSS | PF | |
| Group FWD—Both calls | ✓ | ✓ | | 4 4 + Incoming call distribution group extension no. |
| Group FWD—Outside calls | ✓ | ✓ | | 4 5 + Incoming call distribution group extension no. |
| Group FWD—Intercom calls | ✓ | ✓ | | 4 6 + Incoming call distribution group extension no. |
| Account | ✓ | ✓ | | 4 8 |
| Conference | ✓ | ✓ | | 4 9 |
| Terminate | ✓ | ✓ | | 5 0 |
| External Feature Access (EFA) | ✓ | ✓ | | 5 1 |
| Charge Reference | ✓ | ✓ | | 5 2 |
| Call Park | ✓ | ✓ | | 5 3 + Parking zone no. (2 digits) |
| Call Park (Automatic Park Zone) | ✓ | ✓ | | 5 3 * |
| Call Log* ³ | ✓ | ✓ | | 5 4 |
| Call Log for ICD Group* ³ | ✓ | ✓ | | 5 4 + Incoming call distribution group extension no. |
| Log-in/Log-out | ✓ | ✓ | | 5 5 |
| Log-in/Log-out of a specified group | ✓ | ✓ | | 5 5 + Incoming call distribution group extension no. |
| Log-in/Log-out for all groups | ✓ | ✓ | | 5 5 * |
| Hurry-up | ✓ | ✓ | | 5 6 + Incoming call distribution group extension no. |
| Wrap-up | ✓ | ✓ | | 5 7 |
| System Alarm* ³ | ✓ | ✓ | | 5 8 |
| Time Service (Day/Night/Lunch/Break) | ✓ | ✓ | | 5 9 + 0/1/2/3* ⁴ (+ # + Tenant no.) |
| Answer* ³ | ✓ | ✓ | | 6 0 |

3.1 Customising Your Phone (Personal Programming)

| Buttons | Programmable Button | | | Programming Input |
|---|---------------------|-----|----|--|
| | CO | DSS | PF | |
| Release* ³ | ✓ | ✓ | | 6 1 |
| Toll Restriction/Call Barring | ✓ | ✓ | | 6 2 + Toll Restriction/Call Barring Level (1-7) |
| ISDN Service* ⁵ | ✓ | ✓ | | 6 3 + Desired no. (max. 32 digits) |
| Calling Line Identification Restriction (CLIR) | ✓ | ✓ | | 6 4 |
| Connected Line Identification Restriction (COLR) | ✓ | ✓ | | 6 5 |
| ISDN-Hold | ✓ | ✓ | | 6 6 |
| Headset* ³ ⁶ | ✓ | ✓ | | 6 7 |
| Time Service Switching Mode (Automatic/Manual) | ✓ | ✓ | | 6 8 (+ Tenant no.) |
| Network Direct Station Selection (NDSS)* ⁸ | ✓ | ✓ | | 6 9 + Another PBX extension no. |
| CTI | ✓ | | | 7 0 |
| Check-in* ³ | ✓ | ✓ | | 8 0 |
| Check-out* ³ | ✓ | ✓ | | 8 1 |
| Two-way Record* ⁷ | ✓ | ✓ | | 9 0 + Voice mail floating extension no.* ⁹ |
| Two-way Transfer* ⁷ | ✓ | ✓ | | 9 1 + Voice mail floating extension no.* ⁹ |
| One-touch Two-way Transfer* ⁷ | ✓ | ✓ | | 9 1 + Voice mail floating extension no.* ⁹ + # + Extension no./Incoming call distribution group extension no. |
| Live Call Screening (LCS)* ⁷ | ✓ | ✓ | | 9 2 |
| Voice Mail Transfer* ⁷ | ✓ | ✓ | | 9 4 + Voice mail floating extension no.* ⁹ |



- *1 "×", "#", FLASH/RECALL, PAUSE, SECRET (INTERCOM) and T (Transfer) can also be stored.
If you do not want to display the stored number when making a call, press the SECRET (INTERCOM) button before and after the numbers you wish to conceal.
If you store an outside party's number, you should first store a line access number.
If you need to enter an account code, you can enter the specified account code before the line access number.
<Example>




- *2 For a PF button, "2" is not required to enter before the desired number.
- *3 This button is not available for a PS.
- *4 0: Day/Night/Lunch/Break, 1: Day/Night/Break, 2: Day/Night/Lunch, 3: Day/Night
- *5 Availability of this button depends on the ISDN service of your telephone company. Refer to "1.2.5 Accessing the ISDN Service (ISDN Service Access)".
- *6 This button is not available for the KX-T7665.
- *7 This button is used for the integrated voice mail features.
- *8 The button may not be available depending on the networking method in use or the settings of the PBX. For more details, consult your dealer.
- *9 The default voice mail floating extension number is 500.
- To exit at any time**, lift the handset.



- You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.

To distinguish the ringing tones for each CO, INTERCOM or ICD Group button (Digital proprietary telephone only)




3.1 Customising Your Phone (Personal Programming)



- * Available tone types vary depending on the telephone you are using:
 - KX-T7600 series (except KX-T7665): Tone types "01" to "30" are available.
 - KX-T7665: Only tone types "01" to "08" are available.
It is possible to enter a tone type number from "09" to "30", but you will hear tone type "01".
 - Other telephones: Only tone types "01" to "08" are available.
It is possible to enter a tone type number from "09" to "30", but you will hear tone type "02".

To clear the button



3.2 Manager Programming

3.2.1 Programming Information

The manager can programme the following items.

- Call Charges
- Other Extensions Control

Available Extension

The extension assigned as a manager

Required Telephone

A Panasonic Proprietary Telephone with display (over 2 lines)
(e.g., KX-T7636)

Manager Password


To enter programming mode, the manager password (max. 10 digits) is required. (Default: 1234)

Conditions





The programming extension must be idle, on-hook and holding no calls.

3.2.2 Manager Programming

◆◆ Changing Call Charges and Extension Control



| Item | Programming Input |
|--|---|
| Changing the manager password. | 0 0 + + Password (max. 10 digits) + |
| Viewing extension call charges. | 0 1 + + Extension no. |
| Clearing extension call charges. | 0 1 + + Extension no. + + |
| Setting the budget for extension call charges. | 0 2 + + Extension no. + Charge* + |
| Viewing call charges for each verified code. | 0 3 + + Verified code |
| Clearing call charges for each verified code. | 0 3 + + Verified code + + |
| Setting the budget for each verified code. | 0 4 + + Verified code + Charge* + |
| Viewing call charges for each outside line. | 0 5 + + Outside line no. (3 digits) |
| Assigning a charge rate for each outside line group. | 0 6 + + Outside line group no. (2 digits) + Charge rate* + |
| Clearing all charges. | 0 7 + + |
| Printing the total call charge. | 0 8 + + |
| Locking/unlocking other extensions. (Remote Extension Dial Lock) | 9 0 + + Extension no. + 1 (to lock)/ 0 (to unlock) + |
| Clearing the PIN and PIN lock for extensions. | 9 1 + + Extension no. + |

| Item | Programming Input |
|---|--|
| Clearing the PIN and PIN lock for verified codes. | 9 2 +  + Verified code +  |
| Setting the verified code PIN. | 9 3 +  + Verified code + PIN (max. 10 digits) +  |



- **WARNING**
 There is a risk that fraudulent telephone calls will be made if a third party discovers your password (verified code PIN).
 The cost of such calls will be billed to the owner/renter of the PBX.
 To protect the PBX from this kind of fraudulent use, we strongly recommend:
 - a) Keeping your PIN secret.
 - b) Selecting a complex, random PIN that cannot be easily guessed.
 - c) Changing your PIN regularly.
- * To enter a decimal point, press \times .

3.3 Customising Your System (System Programming)

3.3.1 Programming Information

You can customise your system according to your requirements.
[Your system already has default settings (factory installed).]

The programming is shown below. (Programme number)

- The date and time [000]
- System speed dialling numbers and names [001]/[002]
- Extension number and name [003]/[004]

Available Extension

The extension allowed through COS programming

Required Telephone

A Panasonic Proprietary Telephone with display (over 2 lines)
(e.g., KX-T7636)

System Password

To enter programming mode, the system password (max. 10 digits) is required. (Default: 1234)

Conditions

The programming extension must be idle, on-hook and holding no calls.

List

Before programming, decide the settings and write them down. Your notes will provide a useful record of the programming for future reference. Your dealer also has programming records which contain all of the system programming. You may ask for photo copies of these tables to be aware of the facilities and features available.


Icon Descriptions

| Fixed Buttons | | Function |
|---------------|-------------------|--------------------------------|
| T7600 | T7200/T7400/T7500 | |
| | | PREVIOUS (PREV) |
| | | NEXT |
| | | ➡ |
| | | ⬅ |
| | | STORE (ENTER) |
| | None | Back to Previous Menu (CANCEL) |
| | | SHIFT |
| | | PROGRAM |
| | | END |
| | | SELECT |
| | | FLASH |
| | | CLEAR |
| | | SECRET |

◆◆ Procedure

The basic steps are shown below.

1. *Entering the programming mode*




2. *Programming*

You can enter each programme number (3 digits).



- To exit the programming mode at any time, lift the handset.

3. *Exiting the mode*




- To exit the programming mode at any time, lift the handset.

3.3.2 System Programming


◆◆ Date & Time [000]

The proprietary telephones display the current date and time while on-hook.

[In 12-hour Format]



[In 24-hour Format]






- **After changing the desired values**, you can press the ENTER button. You do not have to perform the rest of the steps.
- The clock starts immediately after the ENTER button is pressed.
- You cannot leave a value empty.
- You can clear the entry by pressing the CLEAR button.
- **To confirm your entry after storing data:**
 - The STORE button light: Lights red
 - Confirmation Tone:
 - One beep: Your entry is accepted.
 - Three beeps: Your entry is rejected.

◆◆ System Speed Dialling Number [001]

You can store the phone numbers of frequently dialled destinations.




- If the desired number is more than 32 digits, divide the number and store it into more than one speed dialling number.
- "×", "#", FLASH/RECALL, PAUSE, and SECRET (INTERCOM) can also be stored.
If you do not want to display the stored number when making a call, press the SECRET (INTERCOM) button before and after the numbers you wish to conceal.
If you store an outside party's number, you should first store a line access number.
If you need to enter an account code, you can enter the specified account code before the line access number.

<Example>

| | | | | |
|--------------------------|--------------|------------------------|------------------------------|--------------------|
| ×49 | 1234 | # | 0/9 | SECRET 123 4567 |
| Account code feature no. | Account code | Account code delimiter | Automatic line access number | Phone number |


◆◆ System Speed Dialling Name [002]

You can store the name associated with the speed dialling number. These names are displayed when making calls using the display operation. To enter characters, refer to "Entering Characters".



◆◆ Extension Number [003]

You can assign an extension number to each extension.




- The leading number(s) should be the same as the number(s) assigned for Flexible Numbering. Consult your dealer.
- A duplicate entry is invalid.

◆◆ Extension Name [004]

You can store the name of an extension user. This is useful if you want to know who is calling, or who you are calling when making an intercom call using the directory.

To enter characters, refer to "Entering Characters".



Section 4







Appendix












This chapter provides the Troubleshooting, the Feature Number Table and Tone List. Check the Troubleshooting section before consulting your dealer.

4.1 Troubleshooting

4.1.1 Troubleshooting

◆◆ Troubleshooting

| Problem | Remedy |
|--|--|
| The telephone does not work properly. | <ul style="list-style-type: none"> ➡ Consult your dealer. |
| I cannot use the telephone. | <ul style="list-style-type: none"> • The telephone is locked. ➡ Unlock your telephone. ( 1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock), 2.1.1 Extension Control) • Your telephone is connected to an eXtra Device Port. ➡ System programming is required. Consult your dealer. |
| Some features do not work. | <ul style="list-style-type: none"> • System management may restrict certain features. ➡ Consult your manager. • The feature numbers have changed. ➡ Confirm the revised number and try again. |
| Even though following the manual instructions, none of the operations work when using a proprietary telephone. | <ul style="list-style-type: none"> • The Intercom line was not seized. The seized line, when going off-hook, was changed by personal setting. ( 3.1.2 Settings on the Programming Mode) ➡ In the manual, going off-hook means an Intercom line is seized. If the setting has been changed, press the INTERCOM button after going off-hook and follow the instructions. |
| The paralleled single line telephones do not ring. | <ul style="list-style-type: none"> • "No ring" may be selected. Change the setting to ring. ( 1.7.11 Setting the Paralleled Telephone to Ring (Paralleled Telephone)) |
| The telephone does not work using the personal settings or with other settings. (One-touch dialling, forwarding destination, etc.) | <ul style="list-style-type: none"> • The extension line has been changed. The previous telephone's settings have not been cleared. ➡ Clear the settings and then programme your desired settings again. ( 1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear), 3.1.1 Customising Your Phone (Personal Programming), 3.1.3 Customising the Buttons) |
| My proprietary telephone does not have a feature button. | <ul style="list-style-type: none"> • Some models do not have the feature button. ➡ Change a flexible button to the desired button. ( 3.1.3 Customising the Buttons) ➡ Enter the specified feature number instead of the feature button. ( 1.1.1 Before Operating the Telephones) |

| Problem | Remedy |
|---|---|
| A reorder tone is audible or "Restricted" is displayed. | <ul style="list-style-type: none"> • The telephone is locked. ➡ Unlock your telephone. ( 1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock), 2.1.1 Extension Control) • Toll restriction is activated. ➡ Consult your manager or dealer. • An account code is required. ( 1.2.7 Calling without Restrictions, Using an Account Code (Account Code Entry) in 1.2.1 Basic Calling) |
| I cannot make an outside call using the One-touch Dialling button or speed dialling. | <ul style="list-style-type: none"> • A line access number was not stored. ➡ A line access number is required for outside calls. ( 1.2.1 Basic Calling, 3.1.3 Customising the Buttons) |
| I cannot remember the feature numbers. | <ul style="list-style-type: none"> • ➡ Ask your dealer to change the feature numbers for easier use. |
| While talking to an outside party, the line is disconnected. | <ul style="list-style-type: none"> • The time limit has run out. ( 1.4.1 Transferring a Call (Call Transfer), 1.4.5 Multiple Party Conversation) ➡ Consult your dealer to extend the time, if necessary. |
| Redialling does not function. | <ul style="list-style-type: none"> • The stored number was more than 32 digits or an extension number. ( 1.2.3 Redial) |
| The personal computer and fax machine communication failed. | <ul style="list-style-type: none"> • An indication tone may have interrupted communication. ( 1.7.9 Protecting Your Line against Notification Tones (Data Line Security)) |
| I do not want to show my telephone number to the calling or called party's telephone. | <ul style="list-style-type: none"> • ➡ Consult your manager or dealer. |
| I want to show my telephone number to the calling or called party's telephone. | <ul style="list-style-type: none"> • ( 1.7.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])) |
| I cannot send a call waiting tone to the dialled extension. | <ul style="list-style-type: none"> • The other party has not set the Call Waiting feature. ( Sending a Call Waiting Notification (Call Waiting), 1.4.4 Answering Call Waiting, 1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)) • The other party has set Data Line Security. ( 1.7.9 Protecting Your Line against Notification Tones (Data Line Security)) |
| I forgot the password. | <ul style="list-style-type: none"> • Ask the manager to assist you. ( 2.1.1 Extension Control) |
| The background music started suddenly. | <ul style="list-style-type: none"> • ➡ Turn off the music. ( 1.7.8 Turning on the Background Music (BGM), 2.1.4 Turning on the External Background Music (BGM)) |

4.1 Troubleshooting

| Problem | Remedy |
|--|--|
| I do not want to display a number which is stored in memory. | <ul style="list-style-type: none"> ➡ Conceal the number. (👉 Storing Names and Numbers, 3.1.3 Customising the Buttons) |
| I want to confirm my extension number. | <ul style="list-style-type: none"> (👉 Your Extension Number in 1.1.1 Before Operating the Telephones) |
| The date and time are not correct. | <ul style="list-style-type: none"> • Set the date and time by system programming. (👉 Date & Time [000] in 3.3.2 System Programming) |
| The display is not shown well. | <ul style="list-style-type: none"> ➡ Change the Display contrast level. (👉 3.1.2 Settings on the Programming Mode) |
| I want to distinguish the tones. | <ul style="list-style-type: none"> (👉 To distinguish the ringing tones for each CO, INTERCOM or ICD Group button (Digital proprietary telephone only), 3.1.3 Customising the Buttons) |
| The MESSAGE button light lit. | <ul style="list-style-type: none"> • Another extension left you a message waiting indication while you were on the phone or away from your desk. |

4.2 Feature Number Table

4.2.1 Feature Number Table

Numbers listed below are the default settings. There are flexible feature numbers and fixed feature numbers. If you change the flexible feature numbers, fill in your assigned numbers (new) in the list for future reference.

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|--|--|---|
| 1.2.1 Basic Calling To call an operator (Operator Call) To select an idle outside line automatically (Automatic Line Access) To select an idle outside line in the specified outside line group automatically (Outside Line Group Access) Making a Call to a Private Network (TIE Line Access) Using an Account Code (Account Code Entry) | 9/0 () 0/9 () 8 () 7 () *49 () | outside phone no. outside line group no. (2 digits) + outside phone no. private phone no. account code + # + outside phone no. |
| 1.2.2 Easy Dialling Using Numbers Stored at Your Extension (Personal Speed Dialling) <ul style="list-style-type: none"> – To store – To dial Using Numbers Stored in the PBX (System Speed Dialling) <ul style="list-style-type: none"> – To dial To a Preset Number by Going Off-hook (Hot Line) <ul style="list-style-type: none"> – To store – To set – To cancel | *30 () ** () ** () *740 () | personal speed dialling no. (2 digits) + phone no. + # * + personal speed dialling no. (2 digits) system speed dialling no. (3 digits) 2 + phone no. + # 1 0 |
| 1.2.3 Redial Redialling the Last Number You Dialed (Last Number Redial) | # () | |

4.2 Feature Number Table

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|---|---|---|
| <p>1.2.4 When the Dialed Line is Busy or There is No Answer</p> <p>To cancel callback ringing (Automatic Callback Busy Cancel)/To cancel (CCBS Cancel)</p> <p>Leaving a Message Waiting Indication/ Calling Back the Caller Who Left an Indication (Message Waiting)</p> <p>For a caller</p> <ul style="list-style-type: none"> – To leave/cancel <p>For a called extension</p> <ul style="list-style-type: none"> – To call back – To clear | <p>✱46 ()</p> <p>✱70 ()</p> | <p>1/0 + extension no.</p> <p>2</p> <p>0 + your extension no.</p> |
| <p>1.2.7 Calling without Restrictions</p> <p>Using Your Calling Privileges at Another Extension (Remote COS Access)</p> <p>To call with a verified code (Verified Code Entry)</p> | <p>✱47 ()</p> | <p>extension no. + extension PIN + phone no.</p> <p>✱ + verified code + verified code PIN + phone no.</p> |
| <p>1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])</p> <p>Calling through DISA</p> <ul style="list-style-type: none"> – To an extension (In All Security Mode only) – To an outside party (In Trunk Security Mode/All Security Mode only) | | <p>your extension no./(✱ + verified code) + extension PIN/verified code PIN + extension no.</p> <p>your extension no./(✱ + verified code) + extension PIN/verified code PIN + outside phone no.</p> |
| <p>1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)</p> <ul style="list-style-type: none"> – From another extension – Through DISA | | <p>your extension no. + extension PIN + feature no.</p> |

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|---|--|---|
| 1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup) Answering a Call from Another Telephone (Call Pickup) <ul style="list-style-type: none"> Group Directed Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny) <ul style="list-style-type: none"> To deny To allow | *40 () *41 () *720 () | group no. (2 digits) extension no. 1 0 |
| 1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS]) <ul style="list-style-type: none"> Calls through an external speaker | *42 () | 1 |
| 1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID]) | *7*3 () | |
| 1.4.1 Transferring a Call (Call Transfer) Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN) | *62 () | phone no. |
| 1.4.2 Holding a Call To hold (Call Hold)/To retrieve a call (Call Hold Retrieve) To retrieve a call (Call Hold Retrieve) <ul style="list-style-type: none"> Specified with a held line number Specified with a holding extension number Holding in a System Parking Zone (Call Park) <ul style="list-style-type: none"> To set To retrieve | *50 () *53 () *51 () *52 () | outside line no. which is held (3 digits) extension no. which has a held call parking zone no. (2 digits)/* stored parking zone no. (2 digits) |

4.2 Feature Number Table

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|--|-------------------|---|
| 1.4.4 Answering Call Waiting Answering Call Waiting in the PBX | *50 () | |
| Answering Call Waiting from the Telephone Company | *60 () | |
| 1.4.5 Multiple Party Conversation Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN) | *62 () | phone no. + TRANSFER button + 3 |
| 1.5.1 Forwarding Calls Forwarding Your Calls (Call Forwarding [FWD])/ 1.7.2 Refusing Incoming Calls (Do Not Disturb [DND]) | | |
| – Both Calls | *710 () | 0 (Cancel)/ |
| – Outside Calls | *711 () | 1 (Do Not Disturb [DND])/ 2 (All calls) + phone no. + #/ 3 (Busy) + phone no. + #/ 4 (No Answer) + phone no. + #/ 5 (Busy/No Answer) + phone no. + #/ 7 (Follow Me) + your extension no./ 8 (Follow Me Cancel) + your extension no. |
| – Intercom Calls | *712 () | 00-99 (second) |
| – To set the timer for "No Answer" and "Busy/No Answer" | *713 () | |
| To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group) | | |
| – Both Calls | *714 () | 1 (Set) + ICD Group extension no. + phone no. + #/0 (Cancel) + ICD Group extension no. |
| – Outside Calls | *715 () | |
| – Intercom Calls | *716 () | |

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|--|---|--|
| Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN) <ul style="list-style-type: none"> To set To cancel To confirm | *7*5 () | outside line no. + # + multiple subscriber no. + # + 2 (Unconditional)/3 (Busy)/4 (No Reply) + phone no. + # outside line no. + # + multiple subscriber no. + # + 0 outside line no. + # + multiple subscriber no. + # + 1 |
| 1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) Recording a Normal Greeting Message <ul style="list-style-type: none"> To record To play back To clear Recording a Greeting Message for Each Time Mode <ul style="list-style-type: none"> To record To play back To clear To leave a voice message directly to another extension's message box Listening to Voice Messages Left by Callers Redirecting Your Calls to Your Message Box <ul style="list-style-type: none"> Both Calls Outside Calls Intercom Calls | *38 () *710 () *711 () *712 () | 1 2 0 8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 1 8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 2 8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 0 # + 6 + extension no. 3 0 (Cancel)/ 2 (All Calls) + floating extension no. for SVM card*5 + #/ 3 (Busy) + floating extension no. for SVM card*5 + #/ 4 (No Answer) + floating extension no. for SVM card*5 + #/ 5 (Busy/No Answer) + floating extension no. for SVM card*5 + # |

4.2 Feature Number Table

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|---|--|---|
| 1.5.3 Showing a Message on the Caller's Telephone Display (Absent Message) <ul style="list-style-type: none"> To set To cancel | *750 () | 1-9 (+ parameter) + # 0 |
| 1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock) <ul style="list-style-type: none"> To lock To unlock | *77 () | 1 0 + extension PIN |
| 1.6.1 Paging Group Paging | *33 () | paging group no. (2 digits) |
| 1.6.2 Answering/Denying a Paging Announcement <ul style="list-style-type: none"> To answer To deny To allow | *43 () *721 () | 1 0 |
| 1.7.1 Setting the Alarm (Timed Reminder) <ul style="list-style-type: none"> To set To cancel | *760 () | 12H: 1 + hour/minute + 0 (AM)/1 (PM) + 0 (once)/1 (daily) 24H: 1 + hour/minute + 0 (once)/1 (daily) 0 |
| 1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA) <ul style="list-style-type: none"> For intercom calls (No call/Tone/OHCA/Whisper OHCA) For outside calls (No tone/Tone) | *731 () *732 () | 0 (No call)/1 (Tone)/2 (OHCA)/3 (Whisper OHCA) 0 (No tone)/1 (Tone) |
| 1.7.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP]) <ul style="list-style-type: none"> Public Your extension | *7*2 () | 1 2 |

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|---|--------------------|-------------------------------------|
| 1.7.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR]) <ul style="list-style-type: none"> – To show – To prevent | *7*0 () | 0 1 |
| 1.7.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR]) <ul style="list-style-type: none"> – To show – To prevent | *7*1 () | 0 1 |
| 1.7.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny) <ul style="list-style-type: none"> – To prevent – To allow | *733 () | 1 0 |
| 1.7.8 Turning on the Background Music (BGM) <ul style="list-style-type: none"> – To set – To cancel | *751 () | 1 0 |
| 1.7.9 Protecting Your Line against Notification Tones (Data Line Security) <ul style="list-style-type: none"> – To set – To cancel | *730 () | 1 0 |
| 1.7.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone) <ul style="list-style-type: none"> – Ring – No Ring | *39 () | 1 0 |
| 1.7.12 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode) <ul style="list-style-type: none"> – To set – To cancel | *48 () | 1 + paired wired extension no. 0 |
| 1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear) | *790 () | |

4.2 Feature Number Table

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|--|---|---|
| 1.8.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up) Log-in Log-out To enter/leave the Not Ready mode | ✖736 () ✖735 () | 1 + ICD Group extension no./✖ 0 + ICD Group extension no./✖ 1 (Not Ready)/0 (Ready) |
| *3 1.8.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor) | ✖739 () | ICD Group extension no. |
| 1.9.1 If a Doorphone/Door Opener is Connected Doorphone Call Opening a Door (Door Open) | ✖31 () ✖55 () | doorphone no. (2 digits) doorphone no. (2 digits) |
| 1.9.2 If an External Relay is Connected | ✖56 () | relay no. (2 digits) |
| 1.9.4 If a Host PBX is Connected Accessing External Services (External Feature Access [EFA]) | ✖60 () | service code |
| 1.9.5 If a Voice Processing System is Connected Call Forwarding to Voice Mail (Voice Mail Integration) – Both Calls – Outside Calls – Intercom Calls | ✖710 () ✖711 () ✖712 () | 0 (Cancel)/ 2 (All Calls)/ 3 (Busy)/ 4 (No Answer)/ 5 (Busy/No Answer) + voice mail floating extension no.*6 + # |
| 1.10.1 Using the Same Settings as Your Previous Extension (Walking Extension) | ✖727 () | your previous extension no. + extension PIN |

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|---|--|--|
| 2.1.1 Extension Control *1 To lock/unlock other extensions (Remote Extension Dial Lock) <ul style="list-style-type: none"> – To unlock – To lock | *782 () *783 () | extension no. extension no. |
| *2 2.1.2 Time Service Mode Control – Day/Night/Lunch/Break | *780 () | 0/1/2/3 |
| *1 2.1.4 Turning on the External Background Music (BGM) <ul style="list-style-type: none"> – To play – To stop | *35 () | 11 10 |
| *1 2.1.5 Recording Outgoing Messages (OGM) <ul style="list-style-type: none"> – To record – To play back – To record from an external BGM (MOH) port – To clear | *36 () | 1 + OGM floating extension no.*7 2 + OGM floating extension no.*7 31 + OGM floating extension no.*7 0 + OGM floating extension no.*7 |
| 2.1.6 Using the Telephones in a Hotel-type Environment (Hospitality Features) *4 Setting a Timed Reminder to a Room Extension (Remote Wake-up Call) <ul style="list-style-type: none"> – To set – To cancel – To confirm Recording room information using a room extension | *76* () *761 () | 12H: 1 + extension no. + hour/minute + 0 (AM)/ 1 (PM) + 0 (once)/1 (daily) 24H: 1 + extension no. + hour/minute + 0 (once)/1 (daily) 0 + extension no. 2 + extension no. message no. (+ parameter) + # |
| *1 2.1.7 Releasing Network Direct Station Selection (NDSS) Monitor | *784 () | another PBX extension no. + # |

4.2 Feature Number Table

| Feature (While dial tone is heard) | Default (New) | Additional digits/buttons |
|--|--------------------|--|
| 3.1.1 Customising Your Phone (Personal Programming) Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number]) <ul style="list-style-type: none"> – To set – To cancel | *799 () | 1 + extension PIN + # + same extension PIN + # 0 + stored extension PIN |

*1: Manager only

*2: Manager and preprogrammed extension user only

*3: Supervisor only

*4: Hotel operator only

*5: The default floating extension numbers are 591 for SVM card 1, and 592 for SVM card 2.

*6: The default voice mail floating extension number is 500.

*7: The default of OGM floating extension numbers is 5xx (xx: two-digit number of message).

| Feature (While busy, DND or call tone is heard) | Default |
|--|---------|
| 1.2.4 When the Dialed Line is Busy or There is No Answer Sending a Call Waiting Notification (Call Waiting) To an Extension Refusing the Call (DND Override) | 1 |
| Joining an Existing Call (Executive Busy Override) | 3 |
| Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting) | 4 |
| Monitoring Another Extension (Call Monitor) | 5 |
| Reserving a Busy Line (Automatic Callback Busy)/Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS]) | 6 |
| 1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice) | × |

| Feature (While dialling or talking) | Fixed Number |
|--|--------------|
| 1.4.5 Multiple Party Conversation Adding Other Parties during a Conversation (Conference) | 3 |
| 1.9.1 If a Doorphone/Door Opener is Connected From any extension while talking to the doorphone | 5 |

4.3 What is This Tone?

4.3.1 What is This Tone?

While on-hook

Ring Tones

The following tones are programmable allowing recognition of call type (Outside, Intercom or Doorphone).


Tone 1




Tone 2



Tone 3



Tone 4




When going off-hook

Dial Tones


Tone 1

Normal



Tone 2


- When there are messages that have previously been listened to and no new messages in your message box
- When any of the following features are set:
 - Absent Message
 - Background Music
 - Call Forwarding
 - Call Pickup Deny
 - Call Waiting
 - Do Not Disturb
 - Extension Dial Lock
 - Executive Busy Override Deny
 - Hot Line
 - Timed Reminder

**Tone 3**

- After pressing TRANSFER or Recall/ hookswitch to hold a call temporarily (e.g., Call Splitting)
- When the recording space of the Built-in Simplified Voice Message feature becomes almost full
- While a called PS is being searched
- When Account Code Entry is performed
- When answering a Timed Reminder call with no message
- When answering an external sensor call


**Tone 4**

Message waiting indication was received.




4.3 What is This Tone?


When you make calls

Busy Tone**Reorder Tone**

The outside line you tried to seize is not assigned or denied.

**Ringback Tone 1****Ringback Tone 2****Do Not Disturb (DND) Tone**


The dialled extension is refusing incoming calls.




While off-hook

Indication Tones**Tone 1**

Call waiting tone

**Tone 2**

A call is on hold longer than the specified time



When talking to an outside party

Warning Tone

This tone is sent 15, 10 and 5 seconds before the specified time for disconnection.



When setting the features or programming

Confirmation Tones**Tone 1**

The feature setting was set successfully.



Tone 2

Before receiving a page through an external speaker

**Tone 3**

Before the following features activate:

- Retrieving a held call
- Picking up another call
- Paging/Answering a paging announcement
- Answering the call through a speaker

**Tone 4**

Establishing or leaving a conference

**Tone 5**

A call has been put on hold.



4.4 Revision History

4.4.1 MPR Version 2.2

New Contents

- 1.1.1 Before Operating the Telephones
 - When You Use a Panasonic Proprietary Telephone
 - Network Direct Station Selection (NDSS)
 - CTI
 - Check-in
 - Check-out
- 1.2.1 Basic Calling
 - Making a Call to a Private Network (TIE Line Access)
 - To call with one touch
- 1.9.2 If an External Relay is Connected
- 1.9.3 If an External Sensor is Connected
- 1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM])
- 2.1.6 Using the Telephones in a Hotel-type Environment (Hospitality Features)
- 2.1.7 Releasing Network Direct Station Selection (NDSS) Monitor

Changed Contents

- 4.3.1 What is This Tone?

Index

Index

A

Absent Message 101, 173, 204
 Accessing External Services (External Feature Access [EFA]) 134
 Accessing System Features (System Feature Access) 152
 Accessing the ISDN Service (ISDN Service Access) 44
 Accessing the Message Box of Another Extension from Your Extension 100
 Accessing Your Message Box from an Outside Telephone 99
 Account 21, 181
 Account Code Entry 29, 199
 Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN) 79
 Adding Other Parties during a Conversation (Conference) 72
 After Moving to a New Location in the Office 141
 Alternate Calling—Ring/Voice 45, 209
 Alternate Receiving—Ring/Voice 172
 Alternating the Calling Method (Alternate Calling—Ring/Voice) 45
 Answer 19, 22, 55, 181
 Answering a Call from Another Telephone (Call Pickup) 53
 Answering a Call Ringing at Another Telephone (Call Pickup) 53
 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS]) 54
 Answering Call Waiting 68
 Answering Call Waiting from the Telephone Company 71
 Answering Call Waiting in the PBX 68
 Answering Calls 51
 Answering Hands-free (Hands-free Answerback) 52
 Answering/Denying a Paging Announcement 107
 Appendix 195
 Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number]) 168
 AUTO ANS (Auto Answer)/MUTE 18
 AUTO DIAL/STORE 17
 Automatic Call Hold 64
 Automatic Callback Busy 35, 209
 Automatic Callback Busy Cancel 36, 200
 Automatic Line Access 26, 199
 Automatic Redial 34

B

Background Music (BGM) 117, 174, 205
 Basic Calling 25
 Before Leaving Your Desk 85
 Before Operating the Telephones 14
 Boss & Secretary feature 85
 Built-in Simplified Voice Message 91, 203
 Busy Station Signalling (BSS) → Call Waiting 37
 Busy Tone 212

C

Call Forwarding (CF)—by ISDN 89, 203
 Call Forwarding (FWD) 19, 85
 Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls 21, 180
 Call Forwarding [FWD] for your Incoming Call Distribution Group 87
 Call Forwarding to Voice Mail (Voice Mail Integration) 135
 Call Hold 62, 201
 Call Hold Retrieve 63, 201
 Call Log 21, 181
 Call Log for ICD Group 21, 181

Call Monitor 43, 209
 Call Park 21, 64, 181, 201
 Call Park (Automatic Park Zone) 21, 64, 181, 201
 Call Park Retrieve 65
 Call Pickup 53
 Call Pickup Deny 53, 201
 Call Splitting 66
 Call Transfer 58
 Call Transfer (CT)—by ISDN 60, 201
 Call Waiting 37, 68, 112, 204
 Call Waiting from the Telephone Company 202
 Call Waiting in the PBX 202
 Call Waiting Selection 173
 Call Waiting Tone 209
 Call Waiting Tone Type Selection 173
 Calling an Outside Party 26
 Calling Another Extension 25
 Calling Line Identification Restriction (CLIR) 22, 115, 171, 182, 205
 Calling through DISA 47
 Calling with the Incoming Call Log 142
 Calling with the Outgoing Call Log 144
 Calling without Restrictions 46
 Calling/Connected Line Identification Presentation (CLIP/COLP) 113, 171, 204
 CANCEL 20
 CCBS Cancel 37, 200
 Changing Call Charges and Extension Control 186
 Changing the Settings of Other Extensions 154
 Charge Reference 21, 181
 Check-in 22, 161, 182
 Checking the Time Service Status 119
 Check-out 22, 162, 182
 Clearing Features 178
 Clearing Features Set at Your Extension (Extension Feature Clear) 122
 CO 17
 Completion of Calls to Busy Subscriber (CCBS) 36, 209
 Conference 19, 21, 72, 181
 Confirmation Tones 212
 Connected Line Identification Restriction (COLR) 22, 114, 182, 205
 Connection Example 24
 Control Features 154
 CTI 22, 182
 Customised Buttons 20
 Customising the Buttons 180
 Customising Your Phone & System 167
 Customising Your Phone (Personal Programming) 168
 Customising Your System (System Programming) 188

D

Data Line Security 118, 205
 Date & Time [000] 191
 Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny) 53
 Dial Tone Transfer 157
 Dial Tones 210
 Direct Inward System Access (DISA) 47
 Direct Station Selection (DSS) 21, 180
 Display 15
 Display Backlight Selection 171

Display Language Selection 171
 Display Lock 175
 Display Switching Mode 171
 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/ COLP]) 113
 DND Override 43, 209
 Do Not Disturb (DND) 19, 110, 202
 Do Not Disturb (DND) Tone 212
 Door Open 131, 206
 Doorphone Call 130, 206
 During a Conversation 58

E

Easy Dialling 30
 Electronic Station Lockout → Extension Dial Lock 103, 175, 204
 ENTER 20
 Entering Characters 148
 Examples 16
 Exclusive Call Hold 62
 Executive Busy Override 41, 209
 Executive Busy Override Deny 116, 174, 205
 Extension Control 154
 Extension Dial Lock 175, 204
 Extension Feature Clear 122, 205
 Extension Name [004] 194
 Extension Number [003] 193
 Extension PIN (Personal Identification Number) 168, 175, 208
 External Background Music (BGM) 158, 207
 External Feature Access (EFA) 21, 134, 181, 206

F

Feature Highlights 2
 Feature Number Table 199
 Feature Numbers 14
 Fixed Buttons 17
 FLASH/RECALL 19
 For Future Reference 8
 Forced Answerback Selection 173
 Forwarding a Waiting Call (Manual Queue Redirection) 129
 Forwarding Calls 85
 Forwarding Your Calls (Call Forwarding [FWD]) 85
 Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN) 89
 FWD N/A Timer 174
 FWD/DND Cycle Switch Mode 88, 110
 FWD/DND Setting Mode 88, 110
 FWD/DND—Intercom calls 21, 180
 FWD/DND—Outside calls 21, 180

G

Group FWD—Both calls 21, 181
 Group FWD—Intercom calls 21, 181
 Group FWD—Outside calls 21, 181
 Group Paging 105, 204
 Group-CO (G-CO) 20, 180

H

Handset/Headset Selection → Headset Operation 83, 174
 Hands-free Answerback 52
 Hands-free operation 82
 Headset 22, 182
 Headset Operation 83, 174
 HOLD 18
 Holding 62
 Holding a Call 62
 Holding in a System Parking Zone (Call Park) 64
 Hot Line 32, 199
 How to Follow the Steps 23
 Hurry-up 21, 181
 Hurry-up Transfer → Manual Queue Redirection 129

I

Icon Descriptions 16, 189
 Identifying Malicious Calling Parties (Malicious Call Identification [MCID]) 57
 If a Doorphone/Door Opener is Connected 130
 If a Host PBX is Connected 134
 If a Voice Processing System is Connected 135
 If an External Relay is Connected 132
 If an External Sensor is Connected 133
 Incoming Call Distribution Group (ICD Group) 21, 180
 Incoming Call Distribution Group Monitor 126, 206
 Incoming Call Log 142
 Indication Tones 212
 INTERCOM 18
 Intercom Call 25
 ISDN Service 22, 182
 ISDN Service Access 44
 ISDN-Hold 22, 182

J

Jog Dial 20
 Joining an Existing Call (Executive Busy Override) 41

K

Key Pad Tone Set 174

L

Last Number Redial 34, 199
 LCS Mode Set (After Answering) 173
 Leaving a Conference (Leaving Three-party Conference) 76
 Leaving a Conference (Unattended Conference) 75
 Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting) 38
 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up) 123
 Leaving Three-party Conference 76
 Leaving Voice Messages 95
 Letting a Third Party Join Your Call (Privacy Release) 78
 Letting Other People Listen to the Conversation (Off-hook Monitor) 82
 Listening to Voice Messages Left by Callers 96
 Live Call Screening 22, 137, 182
 Live Call Screening Mode Set 173
 Log-in/Log-out 21, 123, 181, 206

Index

Log-in/Log-out for all groups 21, 181
 Log-in/Log-out of a specified group 21, 181
 Loop-CO (L-CO) 20, 180

M

Making a Call to a Private Network (TIE Line Access) 28
 Making Calls 25
 Making/Answering an Announcement 105
 Malicious Call Identification (MCID) 57, 201
 Manager Operation 153
 Manager Password 185
 Manager Programming 185, 186
 Manual Queue Redirection 129
 Message 17, 21, 180
 Message for Another Extension 21, 180
 Message Waiting 38, 200, 209
 MODE 20
 MONITOR 18
 Monitoring and Changing the Log-in/Log-out Status of Extensions 127
 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor) 126
 Monitoring Another Extension (Call Monitor) 43
 Monitoring the Status of Waiting Calls 126
 MPR Version 2.2 214
 Multiple Party Conversation 72
 Mute 81

N

Navigator Key 20
 Network Direct Station Selection (NDSS) 22, 182

O

Off-hook Call Announcement (OHCA) 112
 Off-hook Monitor 82
 One-touch Dialling 21, 30, 180
 One-touch Dialling Assignment Mode Selection 175
 One-touch Transfer 59
 One-touch Two-way Transfer 22, 139, 182
 Opening a Door (Door Open) 131
 Operation 13
 Operator Call 26, 199
 Outgoing Call Log 144
 Outgoing Messages (OGM) 159, 207
 Outside Line Group Access 27, 199

P

Paging 105
 Paging and then Transferring a Call 105
 Paging Deny 107, 174
 Parallelled Telephone 120, 172, 205
 PAUSE 17
 Personal Absent Message 173
 Personal Programming 168
 Personal Speed Dialling 30, 199
 Pickup Dialling —> Hot Line 32, 199
 Predialling 27
 Preferred Line Assignment—Incoming 172
 Preferred Line Assignment—Outgoing 172

Preventing Other People from Joining Your Conversation (Executive Busy Override Deny) 116
 Preventing Other People from Using Your Telephone (Extension Dial Lock) 103
 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR]) 115
 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR]) 114
 Privacy Release 78
 PROGRAM 19
 Programmable Feature (PF) 20
 Programming Information 185, 188
 Protecting Your Line against Notification Tones (Data Line Security) 118

Q

Quick Dialling 33

R

Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA) 112
 Receiving Calls 51
 Recording a Conversation 139
 Recording a Greeting Message for Each Time Mode 93
 Recording a Normal Greeting Message 91
 Recording Outgoing Messages (OGM) 159
 Recording room information using a room extension 164
 Redial 17, 34
 Redialling the Last Number You Dialed (Last Number Redial) 34
 Redirecting Your Calls to Your Message Box 94
 Refusing Incoming Calls (Do Not Disturb [DND]) 110
 Registration for Your Portable Station (PS) 14
 Release 20, 22, 55, 182
 Releasing Network Direct Station Selection (NDSS) Monitor 165
 Remote COS Access 46, 200
 Remote Extension Dial Lock 154, 207
 Remote Setting 50, 200
 Remote Station Lock Control —> Remote Extension Dial Lock 154, 207
 Reorder Tone 212
 Required Telephone 185, 188
 Reserving a Busy Line (Automatic Callback Busy) 35
 Restriction Level Control (Dial Tone Transfer) 157
 Restrictions 16
 Revision History 214
 Ring Tones 210

S

Safety Instructions 5
 Screening Calls (Live Call Screening [LCS]) 137
 SELECT 20
 Sending a Call Waiting Notification (Call Waiting) 37
 Setting a Timed Reminder to a Room Extension (Remote Wake-up Call) 163
 Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS]) 36
 Setting Features 170
 Setting the Alarm (Timed Reminder) 108
 Setting the Parallelled Telephone to Ring (Parallelled Telephone) 120
 Setting the Telephone According to Your Needs 108
 Setting Your Telephone from Another Extension or through DISA (Remote

Setting) 50
 Settings on the Programming Mode 170
 SHIFT 20
 Showing a Message on the Caller's Telephone Display (Absent Message) 101
 Single-CO (S-CO) 21, 180
 Soft Buttons 18
 SP-PHONE 17
 Station Programme Clear → Extension Feature Clear 122, 205
 Station Speed Dialling → Personal Speed Dialling 30, 199
 Storing Names and Numbers 147
 System Alarm 21, 181
 System Feature Access 152
 System Password 188
 System Programming 188, 191
 System Speed Dialling 31, 199
 System Speed Dialling Name [002] 193
 System Speed Dialling Number [001] 192

T

Talking to Two Parties Alternately (Call Splitting) 66
 Terminate 21, 181
 Three-party Conference [3PTY]—by ISDN 79, 202
 TIE Line Access 28, 199
 Time Service (Day/Night/Lunch/Break) 21, 119, 155, 181, 207
 Time Service Mode Control 155
 Time Service Switching Mode (Automatic/Manual) 22, 155, 182
 Timed Reminder 108, 204
 To Access Another Party Directly from Outside (Direct Inward System Access [DISA]) 47
 Toll Restriction/Call Barring 22, 182
 Tone 15
 TRANSFER 18
 Transferring a Call (Call Transfer) 58
 Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN) 60
 Transferring to an Extension on the PBX 58
 Transferring to an Outside Party Using the PBX Service 59
 Troubleshooting 196
 Trunk Answer From Any Station (TAFAS) 54, 201
 Turning on the Background Music (BGM) 117
 Turning on the External Background Music (BGM) 158
 Two-way Record 22, 139, 182
 Two-way Transfer 22, 139, 182

U

Unattended Conference 75
 Using a Display Proprietary Telephone 142
 Using a Navigator Key/Jog Dial/Volume Key 15
 Using a Preprogrammed Number (Quick Dialling) 33
 Using an Account Code (Account Code Entry) 29
 Using Numbers Stored at Your Extension (Personal Speed Dialling) 30
 Using Numbers Stored in the PBX (System Speed Dialling) 31
 Using the ANSWER/RELEASE Button 55
 Using the Directories 146
 Using the Headset (Headset Operation) 83
 Using the Same Settings as Your Previous Extension (Walking Extension) 141
 Using the Telephones in a Hotel-type Environment (Hospitality Features)

161
 Using User-supplied Equipment 130
 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) 91
 Using Your Calling Privileges at Another Extension (Remote COS Access) 46
 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode) 121
 Utilising the Call Centre 123

V

Verified Code Entry 46, 200
 VOICE CALL/MUTE 19
 Voice Mail Integration 135, 206
 Voice Mail Transfer 22, 135, 182
 Volume Key 20

W

Walking COS 46
 Walking Extension 141, 206
 Walking Station → Walking Extension 141, 206
 Warning Tone 212
 What is This Tone? 210
 What Kind of Telephone Can Be Used? 14
 When the Dialed Line is Busy or There is No Answer 35
 When You Use a Panasonic Proprietary Telephone 17
 Whisper OHCA 112
 Wireless XDP Parallel Mode 121, 205
 With a One-touch Button (One-touch Dialling) 30
 Wrap-up 21, 123, 181

Y

Your Extension Number 15

Panasonic Communications Co., Ltd.

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

Copyright:

This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© 2004 Panasonic Communications Co., Ltd. All Rights Reserved.